



QAD Adaptive Applications

**User Guide**  
**QAD EQMS Applications:**  
**Equipment Maintenance**

70-3358-2026

QAD QMS Applications version 2026

September 2026

## Copyright

This document contains proprietary information that is protected by copyright and other intellectual property laws. No part of this document may be reproduced, translated, or modified without the prior written consent of QAD Inc. The information contained in this document is subject to change without notice.

QAD Inc. provides this material as is and makes no warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. QAD Inc. shall not be liable for errors contained herein or for incidental or consequential damages (including lost profits) in connection with the furnishing, performance, or use of this material whether based on warranty, contract, or other legal theory.

This document contains trademarks owned by QAD Inc. and other companies.

Copyright © 2026 by QAD Inc

.

QAD Inc.

100 Innovation Place

Santa Barbara, CA 93108

Phone: + 1 (805) 566-6100

<http://www.qad.com>

---

|                                                      |           |
|------------------------------------------------------|-----------|
|                                                      | <b>1</b>  |
| <b>Overview</b>                                      | <b>10</b> |
| About This Guide                                     | 10        |
| <b>Equipment Maintenance Module Setup Guide</b>      | <b>11</b> |
| Setting Up the Equipment Maintenance Module          | 11        |
| Using The Equipment Maintenance Module               | 12        |
| Getting Started                                      | 13        |
| <b>Introduction</b>                                  | <b>15</b> |
| <b>Tooling and Equipment Types</b>                   | <b>15</b> |
| Tooling and Equipment Types States                   | 16        |
| Tooling and Equipment Types Tasks                    | 16        |
| Adding a New Tooling and Equipment Type and Sub-Type | 16        |
| <b>Tooling and Equipment Status</b>                  | <b>16</b> |
| Tooling and Equipment Status States                  | 17        |
| Tooling and Equipment Status Tasks                   | 17        |
| Adding a New Tooling and Equipment Status            | 17        |
| <b>Programs</b>                                      | <b>17</b> |
| <b>Maintenance Fault Codes</b>                       | <b>18</b> |
| Maintenance Fault Codes States                       | 18        |
| Maintenance Fault Codes Tasks                        | 19        |
| Adding a New Maintenance Fault Code                  | 19        |
| <b>Maintenance Teams</b>                             | <b>19</b> |
| Maintenance Teams States                             | 19        |
| Maintenance Teams Tasks                              | 20        |
| Adding a New Maintenance Team                        | 20        |
| <b>Maintenance Work Order Types</b>                  | <b>20</b> |
| Maintenance Work Order Types States                  | 21        |
| Maintenance Work Order Types Tasks                   | 21        |

---

|                                                               |           |
|---------------------------------------------------------------|-----------|
| Adding a New Maintenance Work Order Type .....                | 21        |
| <b>Maintenance Work Order Types Responsibilities .....</b>    | <b>22</b> |
| Maintenance Work Order Types Responsibilities States .....    | 22        |
| Maintenance Work Order Types Responsibilities Tasks .....     | 22        |
| Adding a New Maintenance Work Order Type Responsibility ..... | 22        |
| <b>Production Order Subsystems .....</b>                      | <b>23</b> |
| Production Order Subsystems States .....                      | 23        |
| Production Order Subsystems Tasks .....                       | 24        |
| Adding a New Production Order Subsystem .....                 | 24        |
| <b>Production Order On Hold Reasons .....</b>                 | <b>24</b> |
| Production Order On Hold Reasons States .....                 | 24        |
| Production Order On Hold Reasons Tasks .....                  | 25        |
| Adding a New Production Order On Hold Reason .....            | 25        |
| <b>Cost Accounts .....</b>                                    | <b>25</b> |
| Cost Accounts States .....                                    | 26        |
| Cost Account Tasks .....                                      | 26        |
| Adding a New Cost Account .....                               | 26        |
| <b>Asset Meters .....</b>                                     | <b>26</b> |
| Asset Meters States .....                                     | 27        |
| Asset Meters Tasks .....                                      | 27        |
| Adding a New Asset Meter .....                                | 27        |
| <b>Tooling and Equipment .....</b>                            | <b>30</b> |
| Tooling and Equipment States .....                            | 33        |
| Tooling and Equipment Tasks .....                             | 33        |
| Adding a New Tooling and Equipment Record .....               | 33        |
| Adding Cavities to a Tooling and Equipment Record .....       | 34        |
| Adding a New Tooling and Equipment Usage Log .....            | 34        |
| <b>Maintenance Procedures .....</b>                           | <b>35</b> |

---

|                                                               |           |
|---------------------------------------------------------------|-----------|
| Maintenance Procedures States .....                           | 37        |
| Maintenance Procedures Tasks .....                            | 38        |
| Adding a New Maintenance Procedure .....                      | 38        |
| Adding Tooling and Equipment to a Maintenance Procedure ..... | 39        |
| <b>Maintenance Work Orders Preventive .....</b>               | <b>40</b> |
| Maintenance Work Orders Preventive States .....               | 41        |
| Maintenance Work Orders Preventive Tasks .....                | 42        |
| Adding and Assigning a New Preventive Work Order .....        | 42        |
| Scheduling a Preventive Work Order Series .....               | 43        |
| Completing a Preventive Work Order .....                      | 44        |
| <b>Maintenance Work Orders Reactive .....</b>                 | <b>45</b> |
| Maintenance Work Orders Reactive States .....                 | 46        |
| Maintenance Work Orders Reactive Tasks .....                  | 47        |
| Adding and Assigning a New Reactive Work Order .....          | 47        |
| Completing a Reactive Work Order .....                        | 48        |
| <b>Tooling and Equipment Downtime Logs .....</b>              | <b>49</b> |
| Tooling and Equipment Downtime Logs States .....              | 49        |
| Tooling and Equipment Downtime Logs Tasks .....               | 50        |
| Adding a New Tooling and Equipment Downtime Log .....         | 50        |
| <b>Cost Logs .....</b>                                        | <b>50</b> |
| Cost Logs States .....                                        | 51        |
| Cost Logs Tasks .....                                         | 51        |
| Adding a New Cost Log .....                                   | 51        |
| <b>Asset Usage Log .....</b>                                  | <b>52</b> |
| Asset Usage Log States .....                                  | 52        |
| Asset Usage Log Tasks .....                                   | 53        |
| Adding a New Asset Usage Log .....                            | 53        |
| <b>Introduction to Inbox Messages .....</b>                   | <b>55</b> |

---

|                                                     |           |
|-----------------------------------------------------|-----------|
| Inbox Messages .....                                | 55        |
| <b>Introduction to Metrics and Reports .....</b>    | <b>58</b> |
| Reports .....                                       | 58        |
| Metrics .....                                       | 60        |
| KPIs .....                                          | 60        |
| <b>Security Roles .....</b>                         | <b>62</b> |
| <b>Process Security Roles .....</b>                 | <b>64</b> |
| Tooling and Equipment Types .....                   | 64        |
| Tooling and Equipment Status .....                  | 64        |
| Maintenance Fault Codes .....                       | 65        |
| Maintenance Teams .....                             | 65        |
| Maintenance Work Order Types .....                  | 65        |
| Maintenance Work Order Types Responsibilities ..... | 65        |
| Production Order Subsystems .....                   | 65        |
| Production Order On Hold Reasons .....              | 65        |
| Cost Accounts .....                                 | 65        |
| Asset Meters .....                                  | 65        |
| Tooling and Equipment .....                         | 66        |
| Maintenance Procedures .....                        | 66        |
| Maintenance Work Orders Preventive .....            | 66        |
| Maintenance Work Order Reactive .....               | 66        |
| Tooling and Equipment Downtime Logs .....           | 66        |
| Cost Logs .....                                     | 66        |
| Asset Usage Log .....                               | 67        |
| <b>State Change Security .....</b>                  | <b>67</b> |
| <b>Security .....</b>                               | <b>67</b> |
| Tooling and Equipment Types .....                   | 67        |
| Maintenance Fault Codes .....                       | 67        |

---

|                                          |           |
|------------------------------------------|-----------|
| Maintenance Teams .....                  | 68        |
| Maintenance Work Order Types .....       | 68        |
| Cost Accounts .....                      | 68        |
| Asset Meters .....                       | 68        |
| Production Order Subsystems .....        | 68        |
| Production Order On Hold Reasons .....   | 68        |
| Tooling and Equipment .....              | 69        |
| Maintenance Procedures .....             | 69        |
| Maintenance Work Orders Preventive ..... | 69        |
| Maintenance Work Orders Reactive .....   | 69        |
| Asset Usage Log .....                    | 70        |
| <b>Transactions .....</b>                | <b>70</b> |
| Maintenance Work Order Types .....       | 70        |
| Cost Accounts .....                      | 70        |
| Tooling and Equipment .....              | 71        |
| Maintenance Work Orders Preventive ..... | 71        |
| Maintenance Work Orders Reactive .....   | 72        |
| Cost Logs .....                          | 73        |
| Asset Usage Log .....                    | 74        |
| <b>Commands .....</b>                    | <b>74</b> |
| <b>Frequently Asked Questions .....</b>  | <b>77</b> |

# Equipment Maintenance User Guide

## Change Summary

The following table summarizes significant differences between this document and previous versions.

| Date/Version      | Description                                                  | Reference | Changed By |
|-------------------|--------------------------------------------------------------|-----------|------------|
| DEC 2018/v1.2     | Initial upload                                               | --        | RQT        |
| OCT 2020/v2020.1  | Updated application and process names;<br>Updated versioning | --        | RQT        |
| MAR 2021/v2021    | Updated linkage                                              | --        | RQT        |
| MAY 2021/v2021    | Added a section for Commands                                 | p. 74     | RQT        |
| MAY 2021/v2021.1  | Updated versioning                                           | --        | RQT        |
| FEB 2022/v2022    | Updated versioning                                           | --        | RQT        |
| SEPT 2022/v2022.1 | Updated versioning                                           | --        | RQT        |
| MAR 2023/v2023    | Updated versioning                                           | --        | RQT        |
| MAR 2024/v2024    | Updated versioning                                           | --        | RQT        |
| SEPT 2024/v2024.1 | Updated versioning                                           | --        | RQT        |
| MAR 2025/v2025    | Updated versioning                                           | --        | RQT        |
| SEPT 2025/v2025.1 | Updated versioning                                           | --        | RQT        |
| SEPT 2026/v2026   | Updated versioning                                           | --        | F6J        |

## Chapter 1

# Introduction

*Overview...10*

*Equipment Maintenance Module Setup Guide...10*

*Getting Started...13*

## Overview

Any industry invested in mechanical, engineering, plumbing, or electrical equipment knows that part of the responsibility of owning equipment is maintaining it. With any tool or type of equipment, effective maintenance involves performing routine tasks to keep the machinery in working order and to prevent trouble from surfacing. This maintenance can be broken into two categories: preventive and reactive.

Preventive maintenance pertains to regular maintenance wherein equipment is inspected and adjusted to ensure the machinery continues to function properly and avoid breakdown; examples include changing oil and tooling, cleaning machines, sharpening blades, and so on. A subset of preventive maintenance is predictive maintenance, which uses leading indicators to detect when something is beginning to fail (usually through vibrator, temperature/infrared, and more).

Reactive maintenance is unscheduled maintenance, in which equipment breaks down or malfunctions and now requires repair or replacement, such as jammed gears or broken drive belts.

Maintenance involves more than just assigning responsibilities – it requires time, money, organization, and manpower. The Equipment Maintenance module simplifies, streamlines, and automates the entire equipment maintenance process. It protects the organization's investment in and longevity of its equipment via planning and facilitation of executing on preventive and predictive maintenance activities. Maintenance costs are tracked using a cost log facility that assigns costs to specific accounts; preventive work is scheduled according to routine requirements and asset usage logs; asset tracking enables users to track equipment downtime, assign maintenance teams or individual responsibilities, and manage all aspects of equipment, from time of purchase to end of service.

## About This Guide

This user guide focuses on the:

- Setup required for the Equipment Maintenance module
- Different forms of document organization in the Equipment Maintenance module
- Security and roles for the Equipment Maintenance module
- Instructions for the various Equipment Maintenance tasks

**Note:** This guide does not provide field descriptions for the Equipment Maintenance module fields. Field help is provided in the software.

# Equipment Maintenance Module Setup Guide

This section describes the processes of the Equipment Maintenance module. The list below is arranged by the order in which the processes should be completed, starting with the setup operations and continuing with the main functions.

## Setting Up the Equipment Maintenance Module

### *Tooling and Equipment Types*

Use Tooling and Equipment Types to categorize tools and pieces of equipment that have similar characteristics. See "Tooling and Equipment Types" on page 15.

### *Tooling and Equipment Status*

Use Tooling and Equipment Statuses to provide configurable status levels and categorize tools and equipment by in-service and out-of-service. See "Tooling and Equipment Status" on page 16.

### *Programs*

Use Programs to identify a large project that may include many smaller projects. See "Programs" on page 17.

### *Maintenance Fault Codes*

Use Maintenance Fault Codes to identify why equipment failed during production and provide standard categorization of this information. See "Maintenance Fault Codes" on page 18.

### *Maintenance Teams*

Use Maintenance Teams to create a group of people who can be assigned maintenance work orders. See "Maintenance Teams" on page 19.

### *Maintenance Work Order Types*

Use Maintenance Work Order types to define and categorize high-level groups of maintenance work orders to help with planning and assignment. See "Maintenance Work Order Types" on page 20.

### *Maintenance Work Order Types Responsibilities*

Use Maintenance Work Order Types Responsibilities to determine who will become the responsibility of new work orders created for a specific type. See "Maintenance Work Order Types Responsibilities" on page 22.

### *Production Order Subsystems*

Use Production Order Subsystems to supplement the categorization of work orders so that maintenance knows where to focus their attention during repairs. See "Production Order Subsystems" on page 23.

### ***Production Order On Hold Reasons***

Use Production Order On Hold Reasons to classify why a work order has been placed on hold. See "Production Order On Hold Reasons" on page 24.

### ***Cost Accounts***

Use Cost Accounts to provide billing categories for work log entries in work orders and optionally allow tracking of material quantities. See "Cost Accounts" on page 25.

### ***Asset Meters***

Use Asset Meters to configure counters to determine usage-based maintenance scheduling. See "Asset Meters" on page 26.

## **Using The Equipment Maintenance Module**

### ***Tooling and Equipment***

Use Tooling and Equipment to document the tooling and equipment in the organization. See "Tooling and Equipment" on page 30.

### ***Maintenance Procedures***

Use Maintenance Procedures to create a standardized record for maintenance information. See "Maintenance Procedures" on page 35.

### ***Maintenance Work Order Preventive***

Use Maintenance Work Orders Preventive to assign and document preventive maintenance work for equipment. See "Maintenance Work Orders Preventive" on page 40.

### ***Maintenance Work Orders Reactive***

Use Maintenance Work Orders Reactive to assign and document the results of both preventive and reactive maintenance for assets. See "Maintenance Work Orders Reactive" on page 45.

### ***Tooling and Equipment Downtime Logs***

Use Tooling and Equipment Downtime Logs to track when and why tooling/equipment was taken out of service. See "Tooling and Equipment Downtime Logs" on page 49.

### ***Cost Logs***

Use Cost Logs to document the occurrence of a cost to the organization, typically for helping to determine a cost of quality metric. See "Cost Logs" on page 50.

### ***Asset Usage Log***

Use Asset Usage Logs to log equipment usage for the creation and tracking of preventive maintenance work orders. See "Asset Usage Log" on page 52.

## Getting Started

Before you can begin using the Equipment Maintenance module, it is important to understand the basics of how to navigate and use the EQMS system. The system is intuitive, but some layouts, features, and best practices require a more thorough understanding. See the [User Interface user guide](#) for additional information about the EQMS software.

## Chapter 2

# Setting Up the Equipment Maintenance Module

*Introduction...15*

*Programs...17*

*Tooling and Equipment Types...15*

*Adding a New Tooling and Equipment Type and Sub-Type...16*

*Tooling and Equipment Status...16*

*Adding a New Tooling and Equipment Status...17*

*Maintenance Fault Codes...18*

*Adding a New Maintenance Fault Code...19*

*Maintenance Teams...19*

*Adding a New Maintenance Team...20*

*Maintenance Work Order Types...20*

*Adding a New Maintenance Work Order Type...21*

*Maintenance Work Order Types Responsibilities...22*

*Adding a New Maintenance Work Order Type Responsibility...22*

*Work Order Subsystems...1*

*Adding a New Work Order Subsystem...1*

*Production Order On Hold Reasons...24*

*Adding a New Production Order On Hold Reason...25*

*Cost Accounts...25*

*Adding a New Cost Account...26*

*Asset Meters...26*

*Adding a New Asset Meter...27*

## Introduction

Some preparation is required before tooling and equipment can be added or maintenance procedures set up.

Tooling and equipment definition involves setting up the organization of tooling and equipment by type and status, as well as setting up maintenance types, fault codes (why it failed), and teams responsible for repairs. These tasks are generally performed by the roles of Tooling and Equipment Administrator, Tooling and Equipment Champion, Maintenance Champion, Equipment Maintenance, or Equipment Type Maintenance.

## Tooling and Equipment Types

The first step to setting up tooling and equipment in the system is separating them into different types for better organization. The Tooling and Equipment Types process enables you to categorize tooling and equipment with similar characteristics (such as Conveyors) and allows for standardized reporting on categories, which can optionally be broken down further into subtypes. Tooling and equipment subtypes are more precise, such as "Flat-Belt Conveyor", and are typically used for tracking and categorizing purposes.

Tooling and equipment types are used in the following processes of the Equipment Maintenance module for categorization:

- "Tooling and Equipment" on page 30.
- "Maintenance Procedures" on page 35.
- "Maintenance Work Orders Preventive" on page 40.
- "Maintenance Work Orders Reactive" on page 45.

**Fig. 1: Tooling and Equipment Types screen, General tab**

The screenshot shows the 'General' tab of the 'Tooling and Equipment Sub-Types' screen. It contains the following elements:

- Tooling & Equipment Type Code:** A text input field containing 'IM'.
- Tooling & Equipment Type Name:** A text input field containing 'Injection Molder'.
- Display Expression:** A text input field containing 'IM - Injection Molder'.
- Show on Tooling Worksheets in PQM/RFQ:** A set of three buttons: 'YES', 'NO', and 'UNDECIDED' (which is highlighted in blue).

The General tab is used to define the basic details of a tooling or equipment type.

**Fig. 2: Tooling and Equipment Types screen, Equipment Sub-Types tab**

The screenshot shows the 'Equipment Sub-Types' tab of the 'Tooling and Equipment Sub-Types' screen. It displays a table with the following data:

| Tooling & Equipment Sub-Type Code | Tooling & Equipment Sub-Type Name |
|-----------------------------------|-----------------------------------|
| IM-2                              | 5 Cavity Injection Molder         |
| IM-1                              | 10 Cavity Injection Molder        |

At the bottom of the table, there is a pagination bar showing '1' of 2 items.


The Tooling and Equipment Sub-Types tab allows users to add a sub-type for further categorization and detail.

## Tooling and Equipment Types States

This section defines each state available in the workflow for the Tooling and Equipment Types process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A tooling or equipment type that is actively used.

*Inactive.* A tooling or equipment type that is no longer in use.



## Tooling and Equipment Types Tasks

### Adding a New Tooling and Equipment Type and Sub-Type

1. Select Tooling and Equipment Types from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter values for the tooling and equipment type code and name. Notice how the Display Expression field combines the two values; this is how users will look up this type.
3. Click the Save button to save the new record. When selecting the next state, click Active.
4. Navigate to the Tooling and Equipment Sub-Type tab. Click the Add New Item  button in the Tooling and Equipment Sub-Types field. A new screen opens.
5. Repeat Steps 2-3, this time in the new screen.

**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the type cannot be used for new records.

## Tooling and Equipment Status

The Tooling and Equipment Status process provides configurable status levels and informs the system whether equipment is considered to be in-service or out-of-service. Status examples include Active, Inactive, or Down for Regular Maintenance. If a status is considered active (meaning that the equipment is functioning and in use) then it can be defined as such to let the system know that tooling or equipment with this status is in service.

Tooling and equipment statuses are used in the Tooling and Equipment process to describe why tooling or equipment is active or inactive. See "Tooling and Equipment" on page 30.

**Fig. 3: Tooling and Equipment Status process screen**

The screenshot shows a web form for defining tooling and equipment statuses. It has a 'General' tab selected. The form includes three input fields: 'Status Code' (containing 'RN'), 'Status' (containing 'Running'), and 'Active' (a checked checkbox). Below these is a 'Display Expression' field containing the text 'RN - Running'.

## Tooling and Equipment Status States

This section defines each state available in the workflow for the Tooling and Equipment Status process.

*There are no states defined for this process.*

## Tooling and Equipment Status Tasks

### Adding a New Tooling and Equipment Status

1. Select Tooling and Equipment Status from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter values for the tooling and equipment status code and name. Notice how the Display Expression field combines the two values; this is how users will look up this status.
3. Select the "Active" check box if this status is an active status. This informs the system that any tooling or equipment this status is assigned to is in service.
4. Click the Save button to save the new record.

## Programs

Programs are typically created by large organizations to identify a large project that may include many smaller projects. In the automotive vertical, it is common to see programs involving several part numbers associated with future model builds of a particular vehicle, such as the 2020 Ford Bronco. In the Life Sciences vertical, it is common to have several parts and ingredients associated with a medical device or formula.

Programs contain the overhead information for a project, including the name, location, initiated date, and people involved. The remaining fields of this process are for future functionality.


Programs are used in the Tooling and Equipment process to associate a tool or piece of equipment with a single program. See "Tooling and Equipment" on page 30.

## Maintenance Fault Codes

Maintenance fault codes are used to identify why equipment failed during production and provide standard categorization of this information. Once the cause of a machine's failure is established, this information can be analyzed to improve preventive maintenance on equipment. One example could be if your equipment stopped working and you used a maintenance fault code labeled "Blown Fuse/Breaker". Later, the Tooling and Equipment Administrator can look up how many work orders were submitted under this fault code and determine if there is a bigger problem at hand.

Maintenance fault codes are used in the Maintenance Work Orders Reactive process to identify why a tool or piece of equipment failed. See "Maintenance Work Orders Reactive" on page 45.

**Fig. 4: Maintenance Fault Codes process screen**




The screenshot shows a web form titled "General" for creating or editing a maintenance fault code. It contains three input fields: "Fault Code" with the value "ELCT-3", "Fault Description" with the value "Low Voltage", and "Display Expression" with the value "ELCT-3 - Low Voltage". Each field has a small circular icon to its right.

## Maintenance Fault Codes States

This section defines each state available in the workflow for the Maintenance Fault Codes process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A fault code that is actively used.

*Inactive.* A fault code that is no longer in use.



## Maintenance Fault Codes Tasks

### Adding a New Maintenance Fault Code

1. Select Maintenance Fault Codes from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter values for the fault code and description. Notice how the Display Expression field combines the two values; this is how users will look up this code.
3. Click the Save button to save the new record. When selecting the next state, click Active.

**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the code cannot be used for new records.


## Maintenance Teams

Maintenance teams allow you to create a group of people who can be assigned maintenance work orders. These teams are based on roles and are primarily used for actions. Examples of maintenance teams include Install Equipment, Routine Maintenance, and Hazard Cleanup.

Maintenance teams are used in the Maintenance Work Orders Reactive and Preventive processes to assign the maintenance team responsible for completing the work order. See "Maintenance Work Orders Preventive" on page 40 and "Maintenance Work Orders Reactive" on page 45.

Employees are assigned to maintenance teams in the Maintenance Work Order Types Responsibilities process. See "Maintenance Work Order Types Responsibilities" on page 22.

**Fig. 5: Maintenance Teams process screen**




| Base Role                                                                                       |                                                                                                 |
|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| Name         | Parent Role  |
| Installers                                                                                      | Equipment Maintenance ▼                                                                         |
| Description  |                                                                                                 |
| Install equipment                                                                               |                                                                                                 |

## Maintenance Teams States

This section defines each state available in the workflow for the Maintenance Teams process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A maintenance team that is actively used.

*Inactive.* A maintenance team that is no longer in use.



## Maintenance Teams Tasks

### Adding a New Maintenance Team

1. Select Maintenance Teams from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Add a unique name and description for the maintenance team.
3. Select a parent role from the drop-down list to associate with this maintenance team.
4. Click the Save button to save the new record. When selecting the next state, click Active.

**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the maintenance team cannot be used for new records.

## Maintenance Work Order Types

Maintenance work order types allow you to define and categorize high-level groups of maintenance work orders to help with planning and assignment. These work order types can refer to a general location (such as Tool Room or Facilities), a general process (such as Preventive Maintenance, Change Over, or Calibration), or anything else that may require further categorization (such as Project or Controls). A work order type can determine whether or not a work order requires approval by the owner of that work order.

Maintenance work order types are used in the Maintenance Work Orders Reactive and Preventive processes to classify what type of work order has been requisitioned. See "Maintenance Work Orders Preventive" on page 40 and "Maintenance Work Orders Reactive" on page 45.

**Fig. 6: Maintenance Work Order Types process screen**

**General**

Work Order Type Code ⓘ: RM

Work Order Type Name ⓘ: Reactive Maintenance

Maintenance Type ⓘ: RM

Requires Approval ⓘ: ☒

Display Expression ⓘ: RM - Reactive Maintenance

Responsibility Setup ⓘ

| <input type="checkbox"/> | Default Responsibility | Default Team Responsibility |  |
|--------------------------|------------------------|-----------------------------|--|
| <input type="checkbox"/> | Anny Floyd-ProjMgr     | Maintenance Team            |  |


1 - 1 of 1 items

## Maintenance Work Order Types States

This section defines each state available in the workflow for the Maintenance Work Order Types process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A work order type that is actively used.

*Inactive.* A work order type that is no longer in use.



## Maintenance Work Order Types Tasks

### Adding a New Maintenance Work Order Type

1. Select Maintenance Work Order Types from the left navigation panel. Then, click the Add Item button in the toolbar.
2. Enter values for the work order type code and name. Notice how the Display Expression field combines the two values; this is how users will look up this work order type.
3. Select the type of maintenance this type applies to.
  - **PM** – Preventive Maintenance
  - **RM** – Reactive Maintenance
4. Select the "Requires Approval" check box if this work order type requires approval before it can be completed.

If the "Requires Approval" check box is selected and the Maintenance Type is set to RM, a new field appears titled Responsibility Setup. See "Maintenance Work Order Types Responsibilities" below to learn more about completing this field.

5. Click the Save button to save the new record. When selecting the next state, click Active.


**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the work order type cannot be used for new records.

## Maintenance Work Order Types Responsibilities

Maintenance work order types responsibilities determine who will become the responsibility of new work orders created for a specific type, further filtered by site. You can also use this process to assign a user to a maintenance team.

Maintenance work order types responsibilities are used in the Maintenance Work Order Types process to set up a matrix of default responsibilities for that type. See "Maintenance Work Order Types" on page 20.

**Fig. 7: Maintenance Work Order Types Responsibilities process screen**



## Maintenance Work Order Types Responsibilities States

This section defines each state available in the workflow for the Maintenance Work Order Types process.

*There are no states defined for this process.*

## Maintenance Work Order Types Responsibilities Tasks

### Adding a New Maintenance Work Order Type Responsibility

Maintenance work order type responsibilities are typically set up in the Maintenance Work Order Types process. The field for this setup appears if the work order type's maintenance type is set to RM or if the "Requires Approval" check box is selected.

1. In the Maintenance Work Order Types detail screen, click the Add New Item  button. A new screen appears.
2. Select an individual user and a maintenance team to be the default responsibility of work orders created with this type.
3. Click the Save button.

4. Back in the Maintenance Work Order Types screen, click the Save button one more time. When selecting the next state, click Active.


## Production Order Subsystems

Production order subsystems supplement the categorization of work orders so that maintenance knows where to focus their attention during repairs. For example, if you discovered a hydraulic leak while conducting a PM on a forklift truck, the resulting reactive maintenance work order might be organized as follows:

- Equipment – *Forklift truck*
- Work Order Type – *RM*
- Fault Code – *Fluid leak*
- Production Order Subsystem – *Hydraulic*

Production Order Subsystems are used in the Maintenance Work Orders Reactive process to categorize which part of a piece of equipment requires maintenance. See "Maintenance Work Orders Reactive" on page 45.

**Fig. 8: Production Order Subsystems process screen**




The screenshot shows a web form titled "General". It has three input fields with labels and dropdown icons: "Subsystem Code" containing "HYD", "Subsystem" containing "Hydraulics", and "Display Expression" containing "HYD - Hydraulics".

## Production Order Subsystems States

This section defines each state available in the workflow for the Production Order Subsystems process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A production order subsystem that is actively used.

*Inactive.* A production order subsystem that is no longer in use.



## Production Order Subsystems Tasks

### Adding a New Production Order Subsystem

1. Select Production Order Subsystems from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter values for the subsystem code and name. Notice how the Display Expression field combines the two values; this is how users will look up this subsystem.
3. Click the Save button to save the new record. When selecting the next state, click Active.


**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the subsystem cannot be used for new records.

## Production Order On Hold Reasons

Sometimes unplanned setbacks make it necessary for a work order to be put on hold, preventing it from proceeding or being completed. The reasons for an on hold status vary: perhaps the repairs involve more work than was originally budgeted, or the issue requires more manpower than is available, or maybe maintenance ran out of the materials necessary for completing repairs.

Production order on hold reasons are used in the Maintenance Work Orders Reactive and Preventive processes to classify why the work order has been placed on hold. See "Maintenance Work Orders Preventive" on page 40 and "Maintenance Work Orders Reactive" on page 45.

**Fig. 9: Production Order On Hold Reasons process screen**




The screenshot shows a web application interface for 'Production Order On Hold Reasons'. The 'General' tab is selected. There are three input fields: 'Reason Code' containing 'NSP', 'Reason' containing 'No Spare Parts', and 'Display Expression' containing 'NSP - No Spare Parts'. Each field has a small circular icon with a question mark to its right.

### Production Order On Hold Reasons States

This section defines each state available in the workflow for the Production Order On Hold Reasons process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A production order on hold reason that is actively used.

*Inactive.* A production order on hold reason that is no longer in use.



Production Order On Hold Reasons Tasks

Adding a New Production Order On Hold Reason

- 1. Select Production Order On Hold Reasons from the left navigation panel. Then, click the Add Item  button in the toolbar.
- 2. Enter values for the reason code and name. Notice how the Display Expression field combines the two values; this is how users will look up this reason.
- 3. Click the Save button to save the new record. When selecting the next state, click Active.

**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the reason cannot be used for new records.

Cost Accounts

Cost accounts provide billing categories for work log entries in work orders and optionally allow tracking of material quantities. They are typically tied to the general ledger and allow you to associate costs with the groups defined on the general ledger for cost tracking purposes.

Cost accounts are used by Cost Logs to configure unit quantities and costs. See "Cost Logs" on page 50.

Fig. 10: Cost Accounts process screen

The screenshot shows the 'General' tab of a 'Cost Accounts' form. It contains several input fields and a toggle control:


- GL Account Number**: A text input field containing 'GC HR'.
- Account Description**: A text input field containing 'Gauge Calibration Hours'.
- Display Expression**: A text input field containing 'GC HR - Gauge Calibration Hours'.
- Allow Quantities**: A toggle control with three buttons: 'YES' (highlighted in blue), 'NO', and 'UNDECIDED'.
- Quantity Unit of Measure**: A dropdown menu showing 'hr - Hour' with a minus icon to its right.
- Default Unit Cost**: A text input field containing '3.0000' with a small up/down arrow icon to its right.

## Cost Accounts States

This section defines each state available in the workflow for the Cost Accounts process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A cost account that is actively used.

*Inactive.* A cost account that is no longer in use.



## Cost Account Tasks

### Adding a New Cost Account

1. Select Cost Accounts from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter values for the general ledger account number and account description. Notice how the Display Expression field combines the two values; this is how users will look up this cost account.
3. If you want to allow quantities to be entered for log entries created using this cost account, then set the "Allow Quantities" toggle to YES.
4. If "Allow Quantities" is set to YES, a new field appears titled Quantity Unit of Measure. Select a quantity that will be used for all entries using this cost account (i.e. box).
5. In the Default Unit Cost field, indicate the cost of one unit of the indicated measure (i.e. \$5 per box).
6. Click the Save button to save the new record. When selecting the next state, click Active.

**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the cost account cannot be used for new records.

## Asset Meters

Asset meters are used to configure counters to determine usage-based maintenance scheduling. They can be based on usage logs (manual usage) or a fixed amount per day. Asset meters can be associated with one or more assets, such as equipment, and can then be used to define when

preventive maintenance should occur based on meter thresholds. Examples of asset meters include Number of Parts Produced, Number of Hours Used, or a vehicle's odometer reading.

Asset meters are used by the Asset Usage Log process when usage logs have been selected in order to record equipment usage. See "Asset Usage Log" on page 52.

**Fig. 11: Asset Meters process screen**

The screenshot shows the 'General' tab of the Asset Meters process screen. It contains the following fields and options:


- Meter Code**: A text input field containing 'MIL'.
- Meter Name**: A text input field containing 'Automotive Mileage'.
- Unit of Measure**: A dropdown menu showing 'mi - mile'.
- Meter Type**: Three radio buttons labeled 'USAGE LOG', 'PER DAY' (which is selected), and 'UNDECIDED'.
- Meter Value Type**: Three radio buttons labeled 'ASCENDING' (which is selected), 'DESCENDI...', and 'UNDECIDED'.
- Display Expression**: A text input field containing 'MIL - Automotive Mileage'.

## Asset Meters States

This section defines each state available in the workflow for the Asset Meters process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* An asset meter that is actively used.

*Inactive.* An asset meter that is no longer in use.



## Asset Meters Tasks

### Adding a New Asset Meter

1. Select Asset Meters from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter values for the meter code and name. Notice how the Display Expression field combines the two values; this is how users will look up this asset meter.
3. Select a unit of measure for this meter.
4. Select the meter type to determine the meter's source of values.
  - **Per Day.** Each value is calculated as a fixed number per day, in instances where you know the consumption rate. An example would be the tracking of oil for a

CNC machine. The asset meter would track the amount of oil used per day, since this is used at a fixed rate.

- **Usage Log.** The meter is connected to the Asset Usage Log process, which requires users to manually add records of when equipment is used. An example would be a company car; since the car is not used on a consistent basis, a log must be entered each time the car is driven in order to determine when the oil or other fluids must be changed.

**Note:** The values are not set up in Asset Meters; rather, this process is used as the general configuration. The values will be set in either the Asset Usage Log or Equipment Maintenance Procedure, depending on the Meter Type that is selected.

5. Select the meter value type to determine whether the consumption rate is ascending or descending. There is also an Undecided option.
  - **Ascending.** The meter will count higher. Useful for situations where the meter increments toward a future milestone, such as an odometer.
  - **Descending.** The meter will count lower. Useful for situations where material runs out, such as a gas gauge.
6. Click the Save button to save the new record. When selecting the next state, click Active.

**Note:** You can toggle between Active and Inactive as needed. When the state is Inactive, the asset meter cannot be used for new records.

## Chapter 3

# Using the Equipment Maintenance Module

### *Tooling and Equipment...30*

*Adding a New Tooling and Equipment Record...33*

*Adding Cavities to a Tooling and Equipment Record...34*

*Adding a New Tooling and Equipment Usage Log...34*

### *Maintenance Procedures...35*

*Adding a New Maintenance Procedure...38*

*Adding Tooling and Equipment to a Maintenance Procedure...39*

### *Maintenance Work Orders Preventive...40*

*Adding and Assigning a New Preventive Work Order...42*

*Scheduling a Preventive Work Order Series...43*

*Completing a Preventive Work Order...44*

### *Maintenance Work Orders Reactive...45*

*Adding and Assigning a New Reactive Work Order...47*

*Completing a Reactive Work Order...48*

### *Tooling and Equipment Downtime Logs...49*

*Adding a New Tooling and Equipment Downtime Log...50*

### *Cost Logs...50*

*Adding a New Cost Log...51*

### *Asset Usage Log...52*

*Adding a New Asset Usage Log...53*

# Tooling and Equipment

Tooling and Equipment allows you to document the tools and equipment within your organization. This documentation includes the associated maintenance information, both preventive and reactive for tracking purposes. Tooling and equipment is used in the following processes of the Equipment Maintenance module:

- By Maintenance Procedures to identify which tools and equipment use a specific maintenance procedure. See "Maintenance Procedures" on page 35.
- By Maintenance Work Orders Preventive and Reactive to determine which tools and equipment require maintenance. See "Maintenance Work Orders Preventive" on page 40 and "Maintenance Work Orders Reactive" on page 45.
- By Tooling and Equipment Downtime Logs to determine which tools and equipment are experiencing downtime and requires repairs. See "Tooling and Equipment Downtime Logs" on page 49.
- By Asset Usage Logs to link a tool or piece of equipment to a log that will trigger a preventive maintenance work order. See "Asset Usage Log" on page 52.

Fig. 12: Tooling and Equipment screen, General Asset tab

<

General Asset

General Tooling & Equipment

Cavity Information

Maintenance Procedures

Maintenance Work Orders

Location/Status

>

Asset Number ⓘ

51JY

Asset Description ⓘ

5-Ton Flatbed Truck

Domain ⓘ

10USA - USA Domain

Entity ⓘ

10USACO - USA DIVISION

Site ⓘ

10-302 - Distribution Site 2

Supplier ⓘ

10-300 - QMI -USA Division

Purchase Date ⓘ

2/1/2017

Placed in Service Date ⓘ

2/8/2017

Original Cost ⓘ

20,000.00

Display Expression ⓘ

51JY - 5-Ton Flatbed Truck

Tags ⓘ

|                      | Process | X-Ref | Notes |  |
|----------------------|---------|-------|-------|--|
| No records available |         |       |       |  |

The General tab is used to define the basic details of a tool or piece of equipment.

**Fig. 13: Tooling and Equipment screen, General Tooling & Equipment tab**

The screenshot shows the 'General Tooling & Equipment' tab with the following fields and values:

- Tooling & Equipment Number:** 0045
- Tooling & Equipment Auto Number:** 000004
- Key Tooling & Equipment:** ☒
- Is at Downtime:** ☐
- Tooling & Equipment Description:** 5-Ton Flatbed Truck
- Tooling & Equipment Type:** AUTO - Company Vehicle
- Tooling & Equipment Sub-Type:** TRUCK - Half Ton
- Department:** Enter Department
- Work Center:** Enter Work Center
- Manufacturer:** 910000 - Houston Automotive Group
- Model Number:** 51JY
- Serial Number:** 51JYSN09019019
- Warranty Information:** 10,000 hour transferable warranty, 2791 hours remaining at time of purchase
- Notes:** Purchased used
- Program:** Enter Program
- Display Expression Tooling & Equipment:** 0045 - 5-Ton Flatbed Truck
- Related Tooling & Equipment:** A table with columns: Tooling & Equipment Auto Number, Tooling & Equipment Number, Tooling, and a link icon. It shows 'No records available'.
- Tooling & Equipment Usage:** A table with columns: Usage Date/Time, Notes, and a plus icon. It shows a record for 3/24/2023 9:40 AM with the note 'Chinmont made to Automotive Plant 2'.

The General Tooling & Equipment tab contains most specific details of the tool or equipment, such as the type and sub-type, the manufacturer, the warranty information, and more. Use this tab to indicate if this tool or equipment is vital to the organization, is at downtime, and whether it is used for a single program.

**Fig. 14: Tooling and Equipment screen, Cavity Information tab**

The screenshot shows the 'Cavity Information' tab with a table of cavities:

| <input type="checkbox"/> | Number | Name      | Current State |
|--------------------------|--------|-----------|---------------|
| <input type="checkbox"/> | 10     | Cavity 10 | Active        |
| <input type="checkbox"/> | 9      | Cavity 9  | Active        |
| <input type="checkbox"/> | 8      | Cavity 8  | Inactive      |
| <input type="checkbox"/> | 7      | Cavity 7  | Inactive      |
| <input type="checkbox"/> | 6      | Cavity 6  | Inactive      |
| <input type="checkbox"/> | 5      | Cavity 5  | Inactive      |
| <input type="checkbox"/> | 4      | Cavity 4  | Inactive      |
| <input type="checkbox"/> | 3      | Cavity 3  | Inactive      |

Below the table, there is a 'Number Of Cavities' field set to 10. The bottom right corner indicates '1 - 8 of 8 items'.

Some tools and equipment, such as an injection molding press, contain cavities. The Cavity Information tab allows you to specify how many cavities a machine has and whether they are active. You can also name each cavity, which is useful if they are not identical.

**Fig. 15: Tooling and Equipment screen, Maintenance Procedures tab**

| Work Order Type             | Title              | Current Usage Value |
|-----------------------------|--------------------|---------------------|
| PM - Preventive Maintenance | Change Timing Belt |                     |
| PM - Preventive Maintenance | Change Air Filter  |                     |
| PM - Preventive Maintenance | Change Oil         |                     |

1 - 3 of 3 items

Use the Maintenance Procedures tab to set up the maintenance procedures that apply to the tool or piece of equipment. See "Maintenance Procedures" on page 35 to learn more about completing this tab.

**Fig. 16: Tooling and Equipment screen, Maintenance Work Orders tab**

| Work Order Number | Current State | Work Order Type             | Maintenance Procedure | PM Type  | Scheduled Date | Completed Date/Time |
|-------------------|---------------|-----------------------------|-----------------------|----------|----------------|---------------------|
| 0000008           | In Progress   | PM - Preventive Maintenance | 2 - Change Oil        | Schedule | 1/9/2024       |                     |
| 0000007           | Assigned      | PM - Preventive Maintenance | 3 - Change Air Filter | Schedule | 1/9/2024       |                     |

1 - 2 of 2 items

| Work Order Number | Current State | Work Order Type           | Work Order Title    | Schedule Date | Complete Date/Time |
|-------------------|---------------|---------------------------|---------------------|---------------|--------------------|
| 0000006           | In Progress   | RM - Reactive Maintenance | Transmission Failed | 1/8/2024      |                    |

1 - 1 of 1 items

If there are any maintenance work orders (preventive or reactive) related to the tool or equipment, then list them in the Maintenance Work Orders tab. See "Maintenance Work Orders Preventive" on page 40 and "Maintenance Work Orders Reactive" on page 45 to learn more about completing this tab.

**Fig. 17: Tooling and Equipment screen, Location/Status tab**

Hours in Use Since Maintenance: 41649

Status Date/Time: 4/18/2019 2:12 AM

Usage Frequency Value: 90

Status: RN - Running

Use the Location/Status tab to indicate a tool or equipment's status, frequency of usage, and how many active hours have passed since the last maintenance. This is useful for tools and equipment whose maintenance is scheduled by the number of hours active, rather than by the usage amount.

**Fig. 18: Tooling and Equipment screen, Downtime Log tab**

General Asset

General Tooling & Equipment

Cavity Information

Maintenance Procedures

Maintenance Work Orders

Location / Status

Downtime Log

Downtime ⓘ

|                          |                    |                   |                    |                  |                           |
|--------------------------|--------------------|-------------------|--------------------|------------------|---------------------------|
| <input type="checkbox"/> | Display Expression | Work Order Number | Date/Time Down     |                  | <div>⊕</div> <div>☰</div> |
| <input type="checkbox"/> | A - Day Shift      | 0000006           | 1/8/2024, 10:00 AM |                  |                           |
| <div>⏮ ⏪ 1 ⏩ ⏭</div>     |                    |                   |                    | 1 - 1 of 1 items |                           |

Use the Downtime Log tab to list how many, if any, times that the tool or equipment has been inactive due to a work order. See "Tooling and Equipment Downtime Logs" on page 49 to learn more about completing this tab.


## Tooling and Equipment States

This section defines each state available in the workflow for the Equipment process. See "State Change Security" on page 67 to learn more about how these states transition.

*Active (Default).* A piece of equipment that is actively used.

*Inactive.* A piece of equipment that is no longer in use.

*Retired.* A piece of equipment that has been retired permanently from use.



## Tooling and Equipment Tasks

### Adding a New Tooling and Equipment Record

1. Select Tooling and Equipment from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. In the General Asset tab, enter an asset number and description.
3. Select a supplier, purchase date, and the date that the tool or equipment was placed in service.
4. Navigate to the General Tooling & Equipment tab. Enter an tooling & equipment number and description, then select a tooling & equipment type and sub-type.
5. If this tool or equipment can impact product quality and the ability for the organization to deliver to the customer, then select the "Key Equipment" check box. If this tool or equipment is currently down, then select the "Is at Downtime" check box.

6. Use the remaining fields in this tab to add any additional information about the tool or equipment, such as the model and serial number, warranty information, and general notes.
7. Navigate to the Location/Status tab. Select the tooling & equipment status and the usage frequency value.

**Note:** The usage frequency value determines how many "units of use" (such as hours or usage) should trigger a preventive maintenance work order.

8. Click the Save button to save the new record. When selecting the next state, click Active.

### **Adding Cavities to a Tooling and Equipment Record**

Some items, such as an injection molding press, contain cavities. The Tooling and Equipment process has a tab for tracking these cavities.

1. In the Tooling and Equipment detail screen, navigate to the Cavity Information tab.
2. In the Number of Cavities field, select the maximum amount of cavities used by this item.
3. Click the Save button to save the record. When selecting the next state, click Active.
4. Once the screen has refreshed, note that the Cavities field has automatically populated with the same number of records as you indicated in Step 2.
5. Double-click a cavity record. A new screen appears.
6. Enter the name of the cavity.
7. Click the Save button to save the record. If this is a functioning cavity, select Active. If the cavity is not functioning or not being used, select Inactive.
8. Repeat Steps 5-7 for each cavity record.

**Note:** You can add individual cavities with the Add New Item  button in the Cavities field. The new record screen will open, and you can enter the cavity name and number.

### **Adding a New Tooling and Equipment Usage Log**

Some tools and equipment require preventive maintenance to be conducted based on its usage. This requires users to add entries to an asset usage log, which determines when the next preventive work order should be scheduled.

For information on how to add an asset usage log directly from the Asset Usage Log process, see "Adding a New Asset Usage Log" on page 53.

1. In the Tooling and Equipment process detail screen, navigate to the General Tooling & Equipment tab.
2. Click the Add New Item  button in the Tooling & Equipment Usage field. A new screen appears.
3. Add the appropriate usage unit of measure and usage value. For example, if you are logging the miles driven by a company vehicle, you would select "mi" in the Usage Unit of Measure field and enter the amount of miles in the Usage Value field.
4. Enter notes to give information about this usage, such as where the company vehicle was driven.

5. Click the Save button to save the new record. When selecting the next state, click Update Asset.
6. Back in the Tooling and Equipment screen, scroll back to the Tooling & Equipment Usage field to see each entry. Once enough entries have been added, they will trigger an event that creates a preventive work order.

**Fig. 19: Tooling & Equipment Usage field, Tooling and Equipment process**

The screenshot shows a table titled "Tooling & Equipment Usage" with a header row containing "Usage Date/Time" and "Notes". Below the header is a single data row with the date "2/24/2022, 9:40 AM" and the note "Shipment made to Automotive Plant 3". The table has a pagination bar at the bottom showing "1 - 1 of 1 items".

|                          | Usage Date/Time    | Notes                               |
|--------------------------|--------------------|-------------------------------------|
| <input type="checkbox"/> | 2/24/2022, 9:40 AM | Shipment made to Automotive Plant 3 |

1 - 1 of 1 items

## Maintenance Procedures


Tools and equipment requiring preventive maintenance have specific rules and procedures of how to properly conduct the maintenance. The Maintenance Procedures process provides a standardized record of this maintenance information, and allows the configuration of default usage information.

Some details that may be required for preventive maintenance include the parts required for maintenance, the amount of time required for maintenance and machine downtime, which team is responsible for conducting the maintenance, and more. You may even include the precise steps required for routine maintenance and a copy of the equipment's user manual.

Maintenance procedures are used in the following processes of the Equipment Management module:

- By Maintenance Work Orders Preventive to determine the proper procedure that must be performed during maintenance. See "Maintenance Work Orders Preventive" on page 40.
- By Tooling and Equipment to establish the PM Interval Value and determine the proper procedure that must be performed during maintenance. See "Tooling and Equipment" on page 30.

This process contains commands. See "Commands" on page 74 for more information.

**Fig. 20: Maintenance Procedures screen, General tab**


**General** Procedure Tooling & Equipment Version information

Procedure Number ①: 2

Work Order Type ①: PM - Preventive Maintenance

Title ①: Change Oil

Owner ①: Bob Leipwoski

Default PM Usage Frequency ①: 3,000.0

PM Usage Unit ①: mi - mile

Notes ①: Enter Notes

Default Single Responsibility ①: Enter Default Single Responsibility

Default Team Responsibility ①: Automotive


Default Priority ①: 2

Est. Time to Complete ①: 60.00

Required Downtime ①: 60.00

Display Expression ①: 2 - Change Oil

The General tab is used to define the basic details of a maintenance procedure. If the procedure involves tooling and equipment whose preventive maintenance is based on its usage, then the frequency and unit of usage can be included here. See "Asset Meters" on page 26 for more information about usage logs.

**Fig. 21: Maintenance Procedures screen, Procedure tab**


**General** **Procedure** Tooling & Equipment Version information

Procedure/Instructions ①

Paragraph Select font size A B I U [List Icons]

1. Place vehicle on lift and raise to appropriate height.
2. Unscrew oil cap underneath hood.
3. Place drain pan underneath oil pan drain plug.
4. Unscrew drain plug and wait until pan is completely drained.
5. Place drain pan underneath oil filter.
6. Unscrew oil filter and allow filter to drain into pan.
7. Replace oil filter.
8. Screw in new oil pan drain plug.
9. Fill vehicle with appropriate amount of oil

Parts Required ①: Vehicle, lift, drain pan, oil filter, funnel

Parts List ①

| <input type="checkbox"/> | Item Number | Item Description              | Quantity | Unit of Measure |  |
|--------------------------|-------------|-------------------------------|----------|-----------------|--|
| <input type="checkbox"/> | 304-10020   | 304 Stainless Steel 6" Funnel | 1        | in - inch       |  |

1 - 1 of 1 items

Use the Procedure tab to document the maintenance procedure or give detailed instructions. The Procedure/Instructions field is rich text, which means you can format the text in several ways,

such as insert pictures and hyperlinks or adjust fonts and colors. You should also list any parts or associated documents belonging to this procedure.

**Fig. 22: Maintenance Procedures screen, Tooling & Equipment tab**

| Tooling & Equipment Number | Tooling & Equipment Description | Tooling & Equipment Type | Site                              |
|----------------------------|---------------------------------|--------------------------|-----------------------------------|
| 0045                       | 5-Ton Flatbed Truck             | AUTO - Company Vehicle   | 10-600 - External Distribution Si |

Use this tab to select the tooling and equipment that use this maintenance procedure.

**Fig. 23: Maintenance Procedures screen, Version Information tab**

Change Description

Initial Version

When the Start New Version command is used, this tab contains the change description. The Change Description field must be populated before the record can be made official, even if the current version is the initial version.


## Maintenance Procedures States

This section defines each state available in the workflow for the Maintenance Procedures process. See "State Change Security" on page 67 to learn more about how these states transition.

*Draft (Default).* A maintenance procedure that is still being developed.

*Official.* An official maintenance procedure that is ready for use.

*Obsolete.* An obsolete maintenance procedure that shall no longer be used.



## Maintenance Procedures Tasks


### Adding a New Maintenance Procedure

1. Select Maintenance Procedures from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter a title and select a work order type and owner.
3. If this maintenance procedure will be used in asset usage logs, then complete the Default PM Usage Frequency and PM Usage Unit fields.
4. Select the person or team responsible for completing this procedure.
5. Select a default priority.
6. Set the estimated amount of minutes the procedure will take, as well as the required downtime.
7. Navigate to the Procedure tab. Use the Procedure/Instructions field to document the maintenance instructions. It is best to add all steps and details involved.

**Note:** The Procedure/Instructions tab field uses rich text, which means you can format the text with different fonts and colors, as well as insert pictures and hyperlinks. This is useful for emphasizing caution, displaying diagrams, organizing priorities, and more.

8. Click the Save button to save the new record. When selecting the next state, click Draft.
9. List the parts required for maintenance, then use the Add New Item  button in the Parts List field to link specific items to the record.

**Fig. 24: Maintenance Procedures Parts screen**



10. Click the Save button to save the record. When selecting the next state, click Draft.

## Adding Tooling and Equipment to a Maintenance Procedure

Fig. 25: Tooling & Equipment Maintenance Procedure screen

**General**

Tooling & Equipment ⓘ  
0045 - 5-Ton Flatbed Truck

Maintenance Procedure ⓘ  
2 - Change Oil

Default Priority ⓘ  
2

PM Type ⓘ  
USAGE SCHEDULE UNDECIDED

Asset Meter ⓘ  
MIL - Automotive Mileage

Meter Starting Value ⓘ  
0.0

Meter Unit of Measure ⓘ  
mi - mile

Rate per Day ⓘ  
400.0

PM Interval Value ⓘ  
3,000.0

Current Usage Value ⓘ  
Enter Current Usage Value

Current Usage Percent ⓘ  
40 %

Default Single Responsibility ⓘ  
Enter Default Single Responsibility

Default Team Responsibility ⓘ  
Automotive

**Parts List**

| <input type="checkbox"/> | Item Number | Item Description              | Quantity | Unit of Measure |
|--------------------------|-------------|-------------------------------|----------|-----------------|
| <input type="checkbox"/> | 304-10020   | 304 Stainless Steel 6" Funnel | 1        | EA -            |

1 - 1 of 1 items

Est. Time to Complete ⓘ  
60.00

Required Downtime ⓘ  
60.00

Display Expression ⓘ  
0045 - 5-Ton Flatbed Truck / 2 - Change Oil

- There are two ways to add an equipment entry to a maintenance procedure:
  - In the Maintenance Procedure detail screen, navigate to the Tooling & Equipment tab. Then, click the Add New Item  button in the Tooling & Equipment Maintenance Procedures field. A new screen opens.
  - In the Tooling and Equipment detail screen, navigate to the Maintenance Procedures tab. Then, click the Add New Item button in the Tooling & Equipment Maintenance Procedures field. A new screen opens.
- Select the associated Tooling and Equipment or Maintenance Procedure record. Whichever record the tooling & equipment maintenance procedure originated from, that field is populated by default.

**Note:** You can only select the current maintenance procedure from the drop-down list if it has been saved as Official. Otherwise, it will not appear on the list.

- Select an asset meter. This selection will automatically populate the PM Type, Meter Starting Value, Meter Unit of Measure, and PM Internal Value fields. See "Asset Meters" on page 26 for more information.
- Enter the rate per day that should be used for the selected asset meter.
- Select a default priority and default single or team responsibility.
- Click the Save button to save the record. When selecting the next state, click Active.
- Back in the Maintenance Procedures screen, navigate to the Version Information tab.
- Enter a description in the Change Description field. If this is the first version of the maintenance procedure, then enter Initial Version.
- Click the Save button to save the record. When selecting the next state, click Official.

## Maintenance Work Orders Preventive

Preventive maintenance is an important part of ensuring manufacturing is not interrupted by malfunctioning equipment. It includes tasks such as changing oil, cleaning machines, sharpening blades, and any other routine maintenance that must be regularly completed. Preventive maintenance work orders are used to assign and document preventive maintenance work for equipment.

Maintenance Work Orders Preventive are used in the following processes of the Equipment Management module:

- By Tooling and Equipment to track instances when a preventive maintenance work order was required for a specific tool or equipment. See "Tooling and Equipment" on page 30.
- By Tooling and Equipment Downtime Logs to link which work orders were related to the repairs performed on a tool or piece of equipment. See "Tooling and Equipment Downtime Logs" on page 49.
- By Cost Logs to associate a preventive work order with a cost log. See "Cost Logs" on page 50.

This process contains commands. See "Commands" on page 74 for more information.

**Fig. 26: Maintenance Work Orders Preventive screen, General tab**

The screenshot shows the 'General' tab of the 'Maintenance Work Orders Preventive' screen. The form is organized into several sections with various input fields and dropdown menus. At the top, there are tabs for 'General', 'Progress', and 'Links'. The 'General' tab is active. The form includes fields for 'Work Order Number' (0000009), 'Tooling and Equipment' (LTH1 - Lathe 1), 'Key Equipment' (checkbox), 'Priority' (2), 'Scheduled Date' (1/26/2024), 'Responsibility' (Steve Young-Tech1), 'Team Responsibility' (Maintenance Team), 'Equipment Maintenance Procedure' (LTH1 - Lathe 1 / 5 - Check and clean the filters on the coolant tank), 'Tooling and Equipment Type' (LTH - Lathe), 'Work Order Type' (PM - Preventive Maintenance), 'Maintenance Procedure' (5 - Check and clean the filters on the coolant tank), 'Est.Time to Complete' (1.00), and 'Scheduled Downtime' (3.00). Each field has a small circular icon with a question mark next to it, likely for help or validation.

The General tab defines the basic details of a preventive work order, including the tooling and equipment involved, priority, schedule date, estimated time to completion, and more.

**Fig. 27: Maintenance Work Orders Preventive screen, Progress tab**

General **Progress** Links

Progress or Completion Notes ⓘ  
Filter pump damaged, requires replacement

On-Hold Reason ⓘ  
NSP - No Spare parts

Completed Date/Time ⓘ  
10/3/2024 12:00 PM

Unscheduled Downtime ⓘ  
1.00

Cost Log ⓘ

| <input type="checkbox"/> | Entry Date | Cost Account              | Description        | Total     |
|--------------------------|------------|---------------------------|--------------------|-----------|
| <input type="checkbox"/> | 10/3/2024  | MNT-1 - Maintenance Costs | Coolant pump/motor | 355.00000 |

1 - 1 of 1 items

Work Order Approval ⓘ  
0

The Progress tab is used to track a work order's progress and completion. Cost logs are located in this tab. See "Cost Logs" on page 50.

**Fig. 28: Maintenance Work Orders Preventive screen, Links tab**

General **Progress** **Links**

Domain ⓘ  
10USA - USA Domain

Entity ⓘ  
10USACO - USA DIVISION

Site ⓘ  
10-200 - Auto Industrial Mfg

Department ⓘ  
10-200 MAN - Manufacturing department Auto

Work Center ⓘ  
2382 - Maintenance 2

Related Document(s) ⓘ

| Document Number Obsolete | Document Title | Document File |
|--------------------------|----------------|---------------|
| No records available.    |                |               |

Maintenance Procedure Parts Required ⓘ

| Item Description      | Quantity | Unit of Measure |
|-----------------------|----------|-----------------|
| No records available. |          |                 |

Equipment Maintenance Procedure Parts Required ⓘ

| Item Description      | Quantity | Unit of Measure |
|-----------------------|----------|-----------------|
| No records available. |          |                 |

Tags ⓘ

| <input type="checkbox"/> | Process | X-Ref | Notes |
|--------------------------|---------|-------|-------|
| No records available.    |         |       |       |

The Links tab contains information regarding the domain, site, department, and work center to which the work order is linked. This tab also links various details to the work order, including required parts and related documents (e.g. an instruction manual).

## Maintenance Work Orders Preventive States

This section defines each state available in the workflow for the Maintenance Work Orders Preventive process. See "State Change Security" on page 67 to learn more about how these states

transition.

*New (Default).* A new work order that hasn't been assigned for completion yet.

*Assigned.* The work order has been assigned and is ready to be completed.


*In Progress.* The work order is in progress.

*Complete.* The work order has been completed. If the work order requires approval, it will be flagged as ready for approval at this point.

*Ready for Approval.* The work order is ready for approval.

*Approval Rejected.* The work order approval was rejected and requires additional work to be completed.

*Closed.* The work order has been completed and closed.



## Maintenance Work Orders Preventive Tasks

### Adding and Assigning a New Preventive Work Order

**Note:** If you created a Maintenance Procedure record and set the state to Official, then a Maintenance Work Orders Preventive record has already been created. Filter the search screen to find and open the new record, then proceed to "Scheduling a Preventive Work Order Series" on the next page.

1. Select Maintenance Work Order Preventive from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Enter the scheduled date for the work order. See "Scheduling a Preventive Work Order Series" on the next page to learn how to set up date information for a series.
3. Select the tooling or equipment associated with the work order, then select the appropriate maintenance procedure in the Equipment Maintenance Procedure drop-down

field.

- Note that the entries available in this field are dependent on the Tooling and Equipment field.
  - Once the Equipment Maintenance Procedure field is completed, several other fields in the General and Links tabs are automatically populated.
4. Indicate scheduled downtime if necessary.
  5. Click the Save button to save the new record. When selecting the next state, click Assigned.


**Note:** If you need to set up the date information for a scheduled series, then complete that task before assigning the work order.

### Scheduling a Preventive Work Order Series


Some preventive work orders repeat on a consistent basis, requiring a set frequency and an end option.

1. In the Maintenance Work Order Preventive detail screen, click the Commands button in the toolbar.
2. Select "Change Frequency". A new window opens.
  - a. Choose one of the frequency options, such as Monthly or Quarterly.
  - b. Click OK.

**Fig. 29: Frequency Options dialog**



3. Click the Commands button again. Select "Adjust Schedule Dates".
  - a. Select how many items should always be scheduled.
  - b. Choose one of the end options, such as ending after a set number of occurrences or after a specific date.
  - c. Click OK.

**Fig. 30: Scheduling Options dialog**


**Scheduling options.**

Always have 4 item(s) scheduled

End Option

☐ No end date ☒ End after 12 occurrences ☐ End by

NOTE: You are modifying the frequency for this and all future items.

4. See "Adding and Assigning a New Preventive Work Order" on page 42 for information on completing the rest of the Maintenance Work Order Preventive record. Once everything is complete, click the Save button to save the record. When selecting the next state, click Assigned.

### Completing a Preventive Work Order

1. The person responsible for completing the work order receives a notification, which can be viewed in the Assignment tab in the Actions panel. Use the Actions panel to open the assigned work order.
2. Move the record's state to In Progress, then click the Save button. The Progress tab can now be edited.
3. Navigate to the Progress tab. Add progress notes, indicate unscheduled downtime, and add additional expenses in the Cost Log field (i.e. unplanned work hours, purchase of repair materials, etc.). See "Cost Logs" on page 50.
4. Navigate to the Links tab. Use this tab to view information specific to the tool or equipment that requires maintenance, including the location, the parts required, and related documents (such as a maintenance manual).
5. When you are ready to move the work order to a new state, click the Save button to save the record. When selecting the next state:
  - If the work order is complete, enter the time and date of completion in the Progress tab, then select the state Complete.
  - If the work order's progress is halted, select the state On Hold.
    - In the Progress tab, a new field appears titled On Hold Reason. Enter a description in this field, then click Save.
    - When you are ready to continue the work order, you can switch the state back to In Progress or to Complete.

## Maintenance Work Orders Reactive

Maintenance work orders are used to assign and document the results of both preventive and reactive maintenance for assets. Reactive maintenance is unplanned maintenance, such as when something breaks.

Maintenance work orders reactive are used in the following processes of the Equipment Management module:

- By Tooling and Equipment to track instances when a reactive maintenance work order was required for a specific piece of equipment. See "Tooling and Equipment" on page 30.
- By Tooling and Equipment Downtime Logs to link which work orders were related to the repairs performed on a piece of equipment. See "Tooling and Equipment Downtime Logs" on page 49.
- By Cost Logs to associate a reactive work order with a cost log. See "Cost Logs" on page 50.

**Fig. 31: Maintenance Work Orders Reactive screen, General tab**

The screenshot displays the 'General' tab of the 'Maintenance Work Orders Reactive' screen. The form is organized into several sections with various input fields and dropdown menus. At the top, there are tabs for 'General', 'Progress', and 'Links'. The 'General' tab is active. The form includes fields for 'Work Order Number' (0000004), 'Tooling and Equipment' (IM - Injection Molder - 000003), and 'Key Equipment' (checked). Below these are 'Work Order Type' (RM - Reactive Maintenance) and 'Requested By' (demo superuser). The 'Work Order Title' field contains 'Hydraulic hose leak'. Further down, there are fields for 'Priority' (1), 'Safety or Hazardous Situation' (checked), 'Schedule Date' (2/24/2022), and 'Reported Date/Time' (2/24/2022 9:27 AM). The 'Tooling and Equipment Type' is set to 'IM - Injection Molder', and 'Responsibility' is assigned to 'Anny Floyd-ProjMgr'. The 'Team Responsibility' is 'Maintenance Team'. The 'Est. Time to Complete' is 1.00, and the 'Scheduled Downtime' is 2.00. There is a checkbox for 'Found During PM' which is unchecked. At the bottom, there is a 'Description' field with the placeholder text 'Enter Description'.

The General tab defines the basic details of a reactive work order, including the tooling and equipment involved, priority, schedule date, and more. This tab is also used to indicate whether the equipment involved is a key piece of equipment, whether there is a safety or hazardous situation, and whether this issue was found during a PM.

Fig. 32: Maintenance Work Orders Reactive screen, Progress tab

GeneralProgressLinks

Progress or Completion Notes ⓘ

Cut out the damaged part of the hose and spliced it

On Hold Reason ⓘ

Enter On Hold Reason

Complete Date/Time ⓘ

1/29/2024 10:30 AM

Unscheduled Downtime ⓘ

2.00

Subsystem ⓘ

HYD - Hydraulics

Fault Code(s) ⓘ

| <input type="checkbox"/> | Fault Code | Fault Description |  |
|--------------------------|------------|-------------------|--|
| <input type="checkbox"/> | FL 1       | Fluid Leak        |  |

1 - 1 of 1 items

Cost Log ⓘ

| <input type="checkbox"/> | Entry Date | Cost Account | Description | Total |
|--------------------------|------------|--------------|-------------|-------|
| No records available     |            |              |             |       |

Work Order Approval ⓘ

0

The Progress tab is used to track a work order's progress and completion. Cost logs are located in this tab; see "Cost Logs" on page 50.

Fig. 33: Maintenance Work Orders Reactive screen, Links tab

GeneralProgressLinks

Domain ⓘ

10USA - USA Domain

Entity ⓘ

10USACO - USA DIVISION

Site ⓘ

10-200 - Auto Industrial Mfg

Department ⓘ

10-200 MAN - Manufacturing department Auto

Work Center ⓘ

Enter Work Center

Tags ⓘ

| <input type="checkbox"/> | Process | X-Ref | Notes |
|--------------------------|---------|-------|-------|
| No records available.    |         |       |       |

The Links tab contains information regarding the domain, site, department, and work center to which the work order is linked.

Maintenance Work Orders Reactive States

This section defines each state available in the workflow for the Maintenance Work Orders Reactive process. See "State Change Security" on page 67 to learn more about how these states transition.

*New (Default).* A new maintenance work order. After completing the required information, submit the work order for scheduling.

*Submit.* Select this state to submit the work order for rescheduling.

*Assigned.* The maintenance work order is assigned to be completed.

*On Hold.* The maintenance work order is put on hold. The reason will be noted in the On Hold notes.


*In Process.* The maintenance work order is in the process of completion.

*Complete.* The maintenance work order has been completed by the person responsible.

*Ready for Approval.* The maintenance work order is ready to be reviewed and approved by the designated approvers.

*Approval Rejected.* The approval of the maintenance work order was rejected.

*Closed.* The maintenance work order is closed.



## Maintenance Work Orders Reactive Tasks

### Adding and Assigning a New Reactive Work Order

1. There are two ways to initiate a new reactive work order:
  - a. Select Maintenance Work Order Reactive from the left navigation panel. Then, click the Add Item  button in the toolbar.

- b. In the Tooling and Equipment process detail screen, navigate to the Maintenance Work Orders tab. Click the Add New Item  button in the Reactive field. A new screen opens.
  2. Add values for the following fields:
    - a. Tooling and Equipment
    - b. Work Order Type
    - c. Work Order Title
    - d. Responsibility or Team Responsibility
- Note:** If the work order was created from the Tooling and Equipment process, then corresponding field is automatically populated.
3. Select a schedule date.
  4. Select any check box that applies to this work order:
    - **Key Equipment.** Does this work order involve tooling or equipment that is key to the organization?
    - **Safety or Hazardous Situation.** Does this work order involve a safety or hazard situation?
    - **Found During PM.** Was this issue discovered during a preventive maintenance work order?
  5. Enter a description and any recommendations about how to address the work order. If you selected the "Safety or Hazardous Situation" check box, then add the related notes to the Description field.
  6. Click the Save button to save the new record. When selecting the next state:
    - a. If you are the assigner, select Assigned.
    - b. If you are not the assigner, select Submit.

### Completing a Reactive Work Order

1. The person responsible for completing the work order receives a notification, which can be viewed in the Assignment tab in the Actions panel. Use the Actions panel to open the assigned work order.
2. Move the record's state to In Progress, then click the Save button. The Progress tab appears.
3. Navigate to the Progress tab. Select a subsystem and any applicable fault codes.
4. Add progress notes, indicate unscheduled downtime, and add additional expenses in the Cost Log field (e.g. unplanned work hours, purchase of new materials, etc.). See "Cost Logs" on page 50.
5. Navigate to the Links tab. Use this tab to view the location of the tooling and equipment that requires maintenance.
6. When you are ready to move the work order to a new state, click the Save button to save the record. When selecting the next state:
  - If the work order is complete, enter the time and date of completion in the Progress tab, then select the state Complete.
  - If the work order's progress is halted, select the state On Hold.
    - In the Progress tab, a new field appears titled On Hold Reason. Enter a description in this field, then click Save.

- When you are ready to continue the work order, you can switch the state back to In Progress or to Complete.

## Tooling and Equipment Downtime Logs

Tooling and equipment downtime logs are used every time you take tooling or equipment out of service so you can make a note of why it was removed and which work orders are related to this decision. This manual process is best suited for a major overhaul-type situation, such as when a machine is pulled off the floor for a few weeks of refurbishment. Downtime does not apply to when the machine is offline for basic maintenance or other brief, routine work.

Tooling and equipment downtime logs are used in the following processes of the Equipment Maintenance module:

- By Tooling and Equipment to keep track of how many times a tool or equipment has been in downtime. See "Tooling and Equipment" on page 30.
- By Maintenance Work Orders Preventive and Reactive to track the amount of time needed for scheduled or unscheduled downtime. See "Maintenance Work Orders Preventive" on page 40 and "Maintenance Work Orders Reactive" on page 45.

**Fig. 34: Tooling and Equipment Downtime Logs process screen**

**General**

Date/Time Down ⓘ 1/15/2024 1:00 PM

Tooling and Equipment ⓘ IM - Injection Molder - 000003

Shift ⓘ A - Day Shift

Reason ⓘ Leak in hydraulic hose

Repairs ⓘ Damaged part of hose was removed, spliced with new section

Date/Time Restart ⓘ 1/15/2024 4:00 PM

Work Orders ⓘ

| <input type="checkbox"/> | Work Order Number | WO Type                   | WO Equipment                   |  |
|--------------------------|-------------------|---------------------------|--------------------------------|--|
| <input type="checkbox"/> | 0000004           | RM - Reactive Maintenance | IM - Injection Molder - 000003 |  |

1 - 1 of 1 items

Site ⓘ 10-200 - Auto Industrial Mfg

Department ⓘ 10-200 MAN - Manufacturing department Auto

Work Center ⓘ Enter Work Center

Stop Duration ⓘ Length of time equipment was not running in hours : 3

## Tooling and Equipment Downtime Logs States

This section defines each state available in the workflow for the Tooling and Equipment Downtime Logs process.

*There are no states defined for this process.*

## Tooling and Equipment Downtime Logs Tasks

### Adding a New Tooling and Equipment Downtime Log

1. There are two ways to initiate a tooling and equipment downtime log:
  - a. Select Tooling and Equipment Downtime Logs from the left navigation panel. Then, click the Add Item  button in the toolbar.
  - b. In the applicable Tooling and Equipment detail screen, navigate to the Downtime Log tab. Then, click the Add New Item  button in the Downtime field. A new screen opens.
2. Select the date and time when the tool or equipment is put in downtime.
3. Assign the tool or equipment and the shift. The Tooling and Equipment field automatically populates the Site, Department, and Work Center fields.

**Note:** If you created the downtime log from a Tooling and Equipment record, then the Tooling and Equipment field is automatically populated.

4. If the tool or equipment has already been repaired, use the Repairs field to explain what was done to fix the item.
5. Use the Date/Time Restart field to indicate when the repairs were completed.
6. Link any related work orders to the downtime log.
  - a. Click the Link  button in the Work Orders field. A new window opens.
  - b. Select any items that apply.
  - c. Click OK.
7. Click the Save button to save the new record.

## Cost Logs

Cost log records document the occurrence of a cost to the organization, typically for helping determine a cost of quality metric. A cost log entry can be initiated from several different processes:

- Gauges
- Maintenance Work Orders Preventive and Reactive
- Nonconformances
- Containment Actions
- Projects
- Project Tasks
- Training Events

Cost logs are used in both Preventive and Reactive Work Orders to provide tracking of maintenance costs. See "Maintenance Work Orders Preventive" on page 40 and "Maintenance Work Orders Reactive" on page 45.

**Fig. 35: Cost Logs screen, General tab**

The screenshot shows the 'General' tab of the Cost Logs screen. It features several input fields and dropdown menus. The 'Entry Date' is set to 2/28/2023. The 'Cost Account' is 2720 - Containment activities. The 'Quantity' is 2.00 and the 'Unit of Measure' is hr - Hour. The 'Unit Cost' is \$25.00000 and the 'Total' is 50.00000. The 'Currency' is United States Dollar. The 'Description' is 'Cost to inspect product and execute corrective actions'. The 'Domain' is 10USA - USA Domain, 'Entity' is 10USACO - USA DIVISION, 'Site' is 10-200 - Auto Industrial Mf, and 'Department' is Enter Department. The 'Work Center' is Enter Work Center and 'Num/Percentage' is 50 %.

The General tab is used to set up a majority of the cost log details, including the cost account, unit cost, description, and more.

**Fig. 36: Cost Logs screen, Links tab**

The screenshot shows the 'Links' tab of the Cost Logs screen. It features two main input fields: 'Employee' (demo superuser) and 'Containment Action' (0000050). Below these is a table with columns for 'Tags', 'Process', 'X-Ref', and 'Notes'. The table is empty, showing 'No records available.'

The Links tab contains fields that appear when the cost log is created from another record, such as a work order, nonconformance, or project task.

## Cost Logs States

This section defines each state available in the workflow for the Cost Logs process.

*There are no states defined for this process.*

## Cost Logs Tasks

### Adding a New Cost Log

- There are two ways to initiate a new cost log:
  - Select Cost Logs from the left navigation panel. Then, click the Add Items  button in the toolbar.
  - In the applicable process, click the Add New Item  button in the Cost Logs field. A new window opens. See the Cost Logs introduction to see a list of applicable processes.
- Select a cost account. If the cost account allows quantities, then two fields appear: Quantity and Unit of Measure. The Unit of Measure field automatically populates.

3. Select the unit cost and, if applicable, the quantity. The Total field automatically populates.
4. Enter a detailed description of the cost log entry.
5. Click the Save button to save the new record.

## Asset Usage Log

Some tooling and equipment requires preventive maintenance to be conducted based on its usage. This requires users to add entries to an asset usage log, which determines when the next preventive work order should be scheduled. If you selected "Usage Log" in the asset meter applied to the Tooling and Equipment record, then you will use asset usage logs. See "Tooling and Equipment" on page 30.

**Fig. 37: Asset Usage Log process screen**

The screenshot shows the 'General' tab of the Asset Usage Log process screen. It includes the following fields and values:

- Usage Date/Time:** 2/24/2022 09:40
- Tooling and Equipment:** - 5-Ton Flatbed Truck
- Usage Unit of Measure:** mi - mile
- Usage Value:** 65.0
- Notes:** Shipment made to Automotive Plant 3


## Asset Usage Log States

This section defines each state available in the workflow for the Asset Usage Log process. See "State Change Security" on page 67 to learn more about how these states transition.

*New (Default).* A new asset usage log item that has not yet been used to update the asset's usage.

*Update Asset.* Select this state to update the asset's usage.

*Complete.* The asset's usage has been updated. This log record can no longer be changed.



## Asset Usage Log Tasks

### Adding a New Asset Usage Log

For information on how to add an asset usage log directly from the Tooling and Equipment process, see "Adding a New Equipment Usage Log" on page 1.

1. Select Asset Usage Log from the left navigation panel. Then, click the Add Item  button in the toolbar.
2. Select either a gauge or a tool/equipment from the respective drop-down field.
3. Add the appropriate usage unit of measure and usage value. For example, if you are logging the miles that a company car has driven, you would select "mi" in the Usage Unit of Measure field and enter the amount of miles in the Usage Value field.
4. Enter notes to give information about this usage, such as where the company car was driven to.
5. Click the Save button to save the new record. When selecting the next state, click Update Asset.

Chapter 4

# Inbox Messages

*Introduction...55*

*Inbox Messages...55*

## Introduction to Inbox Messages

Most processes in the system require multiple people, departments, or groups to coordinate on completing a process. The inbox automates notifications sent to the appropriate users at specific times in the process.

An individual inbox action item represents a single task, approval, or notification that has been sent to you. This task will remain in your inbox until the necessary steps have been taken for completion.

Inbox messages can be separated into three different action types:

- **Assignment.** You are required to take some action in the system to move it beyond your workflow.
- **Approval.** Your approval is requested. You must approve or reject the process item.
- **Acknowledgment.** This is only for your information. You can acknowledge the notification to remove it from your inbox.

See the [User Interface](#) user guide to learn how to access inbox messages.

## Inbox Messages

The table below describes each inbox action item involved in the Equipment Maintenance module. In addition to title and description, the table indicates which process each item comes from, who receives the message, and when it is sent. See the [User Interface](#) user guide to learn more about inbox messages.

| Process                            | Title                                                      | Message                                                                                                                                                                | Action Type | Sent To / Sent When                                                                                            |
|------------------------------------|------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|----------------------------------------------------------------------------------------------------------------|
| Maintenance Work Orders Preventive | Responsibility and Champion – Work Order Has Been Rejected | Work Order Number: {WorkOrderNumber_f}<br><br>Tooling and Equipment: {Equipment_f}<br><br>Procedure: {MaintenanceProcedure_f}<br><br>Scheduled Date: {ScheduledDate_f} | Assignment  | Sent to the Maintenance Champion and responsible users when the current state is moved to Approval Rejected.   |
| Maintenance Work Orders Preventive | Responsibility – Work Order is Assigned                    | Work Order Number: {WorkOrderNumber_f}<br><br>Tooling and Equipment: {Equipment_f}<br><br>Procedure: {MaintenanceProcedure_f}                                          | Assignment  | Sent to the responsible users when the work order's state is Assigned and responsibilities have been assigned. |

| Process                          | Title                                                      | Message                                                                                                                                               | Action Type | Sent To / Sent When                                                                                          |
|----------------------------------|------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|--------------------------------------------------------------------------------------------------------------|
|                                  |                                                            | Scheduled Date:<br>{ScheduledDate_f}                                                                                                                  |             |                                                                                                              |
| Maintenance Work Orders Reactive | Responsibility and Champion – Work Order Has Been Rejected | Work Order Number:<br>{WorkOrderNumber_f}<br><br>Title: {WorkOrderTitle_f}<br><br>Equipment: {Equipment_f}<br><br>Scheduled Date:<br>{ScheduleDate_f} | Assignment  | Sent to the Maintenance Champion and responsible users when the current state is moved to Approval Rejected. |
| Maintenance Work Orders Reactive | Responsibility – Work Order is Submitted                   | Work Order Number:<br>{WorkOrderNumber_f}<br><br>Title: {WorkOrderTitle_f}<br><br>Equipment: {Equipment_f}<br><br>Scheduled Date:<br>{ScheduleDate_f} | Assignment  | Sent to the responsible users when the current state is Submitted and responsibilities have been assigned.   |
| Maintenance Work Orders Reactive | Responsibility – Work Order is Assigned                    | Work Order Number:<br>{WorkOrderNumber_f}<br><br>Title: {WorkOrderTitle_f}<br><br>Equipment: {Equipment_f}<br><br>Scheduled Date:<br>{ScheduleDate_f} | Assignment  | Sent to the responsible users when the current state is Assigned and responsibilities have been assigned.    |

## Chapter 5

# Metrics and Reports

*Introduction...58*

*Reports...58*

*Metrics...60*

*KPIs...60*

## Introduction to Metrics and Reports

The QMS system includes reporting and metric features that let you analyze the data in each process, measuring efficiency and effectiveness. The metrics and reports available differ between each process.

Reports are generated within each process, either from the search screen or the detail screen. Metrics and key process indicators (KPIs) are gadgets that can be placed on one of your dashboards.

See the [User Interface user guide](#) to learn how to generate reports, metrics, and KPIs.

### Reports

Pre-set reports are available on a process by process basis, though not every process has a pre-set report. Certain reports require additional parameters in order to be previewed. The parameters are listed on the right side of the preview window. If a report requires parameters, then this pane will automatically appear. Once you have selected the desired parameters, click the Preview button to see the report preview.

Below is a table that describes each report available in the Equipment Maintenance module. In addition to title and description, the table indicates which process each report comes from and whether it is pulled from the search screen or detail screen. Lastly, if the report requires specific parameters in order to be generated properly, a description of those parameters is included below that report. See the [User Interface user guide](#) to learn how to access reports.

| Process                                       | Pulls From    | Title                                           | Description                                                                                    |
|-----------------------------------------------|---------------|-------------------------------------------------|------------------------------------------------------------------------------------------------|
| Tooling and Equipment Types                   | Detail Screen | Audit Trail – Equipment Types                   | Provides a path of how the record has progressed over time with changes (who, what, and when). |
| Tooling and Equipment Status                  | Detail Screen | Audit Trail – Equipment Status                  | Provides a path of how the record has progressed over time with changes (who, what, and when). |
| Maintenance Fault Codes                       | Detail Screen | Audit Trail – Maintenance Fault Codes           | Provides a path of how the record has progressed over time with changes (who, what, and when). |
| Maintenance Teams                             | Detail Screen | Audit Trail – Maintenance Teams                 | Provides a path of how the record has progressed over time with changes (who, what, and when). |
| Maintenance Work Order Types                  | Detail Screen | Audit Trail – Maintenance Work Order Types      | Provides a path of how the record has progressed over time with changes (who, what, and when). |
| Maintenance Work Order Types Responsibilities | Detail Screen | Audit Trail – Maintenance Work Order Types Resp | Provides a path of how the record has progressed over time with changes (who, what, and when). |
| Production Order Subsystems                   | Detail Screen | Audit Trail – Production Order                  | Provides a path of how the record has progressed over time with changes (who, what, and when). |

|                                     |                          |                                                   |                                                                                                                                                                                                                   |
|-------------------------------------|--------------------------|---------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                     |                          | Subsystems                                        |                                                                                                                                                                                                                   |
| Production Order On Hold Reasons    | Detail Screen            | Audit Trail – Production Order On Hold Reasons    | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Cost Accounts                       | Detail Screen            | Audit Trail – Cost Accounts                       | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Asset Meters                        | Detail Screen            | Audit Trail – Asset Meters                        | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Tooling and Equipment               | Detail Screen            | Audit Trail – Tooling and Equipment               | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Maintenance Procedures              | Detail Screen            | Audit Trail – Maintenance Procedures              | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Maintenance Work Orders Preventive  | Detail Screen            | Audit Trail – Maintenance Work Orders Preventive  | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Maintenance Work Orders Preventive  | Detail and Search Screen | Preventive Work Order Report                      | Provides a work order report showing the details of the work order. This report can be run based on parameters that the user can define from the search screen or as an individual report from the detail screen. |
| Maintenance Work Orders Preventive  | Search Screen            | Preventive Work Order Report No Parameters        | Provides the details of the work orders based on the filter applied to the search screen.                                                                                                                         |
| Maintenance Work Orders Preventive  | Search Screen            | PM Work Order Percent Used                        | Accepts a percentage (as a float) that will show a table of all work orders that would be due based on the equipment's current usage percentage.                                                                  |
| Maintenance Work Orders Reactive    | Detail Screen            | Audit Trail – Maintenance Work Orders Reactive    | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Maintenance Work Orders Reactive    | Detail Screen            | Reactive Work Order Report                        | Provides a work order report showing the details of the work order.                                                                                                                                               |
| Tooling and Equipment Downtime Logs | Detail Screen            | Audit Trail – Tooling and Equipment Downtime Logs | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Cost Logs                           | Detail Screen            | Audit Trail – Cost Logs                           | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |
| Asset Usage Log                     | Detail Screen            | Audit Trail – Asset Usage Log                     | Provides a path of how the record has progressed over time with changes (who, what, and when).                                                                                                                    |

## Metrics

Below is a table that describes each metric available in the Equipment Maintenance module. In addition to title and description, the table indicates which process each metric comes from. Lastly, if the metric requires specific parameters in order to be generated properly, a description of those parameters is included below that metric. See the [User Interface user guide](#) to learn more about metrics.

| Process                             | Pulls From | Title                                  | Description                                                                       |
|-------------------------------------|------------|----------------------------------------|-----------------------------------------------------------------------------------|
| Maintenance Work Orders Preventive  | Gadgets    | On Time Completion Percentage by Month | The percentage of work orders completed on time in a given month.                 |
| Tooling and Equipment Downtime Logs | Gadgets    | Sums Duration group by Department      | Shows the duration of downtime by department for a given date range.              |
| Tooling and Equipment Downtime Logs | Gadgets    | Sums Duration group by Equipment       | Shows the duration of downtime by an individual equipment for a given date range. |
| Tooling and Equipment Downtime Logs | Gadgets    | Sums Duration group by Equipment Type  | Shows the duration of downtime by equipment type for a given date range.          |

## KPIs

See the [User Interface user guide](#) to learn more about KPIs.

***There are no KPIs defined for this module.***

## Chapter 6

# Security Settings

*Module Security Roles...62*

*Process Security Roles...64*

*State Change Security...67*

*Transactions...70*

*Commands...74*

## Security Roles

Security roles define how various users access and control different types of processes and data. These roles are then assigned to each user. Some roles are used by many users, while others may only be applied to one or two individuals.

Because the Equipment Maintenance module contains fields whose data pulls from other modules, some external security roles are adopted as necessary for full integration.

The following security roles apply in the Equipment Maintenance module.

### ***All Roles***

This security role is a system-controlled All Roles value. Any security applied to this special system role grants that security access to all users of the system.

### ***APQP Administrator***

This security role allows you to add, edit, and remove records in any process in the APQP module.

### ***APQP Champion***

This security role allows you to add records in any process in the APQP module.

### ***APQP Maintenance***

This security role allows you to add, edit, and remove specification names, process symbols, special symbols, FMEA detection/occurrence/severity ratings, frequency events, drawing types, and control methods. Besides being able to add and remove items for those processes, you can also view and edit all of the fields of the processes noted. Typically this maintenance account is only given to one or two individuals who are responsible for setting up this data for others to use.

### ***APQP Navigation***

This security role allows you to navigate to the APQP module.

### ***Asset Usage Log Add/Edit***

This security role allows you to add new and edit asset usage log items.

### ***Cost Log Add/Edit***

This security role allows you to add new and edit cost log items. Upon adding a cost log record you will become the person who logged the record by default. Only the person who logged the record or the Cost Log Administrator security role will be able to edit the cost log record.

### ***Cost Log Administrator***

This security role allows you to add new costs log accounts and cost logs. The Cost Log Administrator also has the ability to edit any cost log as if they were the employee who entered

the cost log record.

### ***Equipment Add***

This security role allows you to add new and edit equipment.

### ***Equipment Add/Edit***

This security role allows you to add new and edit equipment.

### ***Equipment Maintenance***

This security role allows you to add, edit, and remove equipment types, equipment sub-types, equipment status, equipment cavity, equipment downtime logs, and asset meters. Typically this maintenance account is only given to one or two individuals responsible for setting up this data for others to use.

### ***Equipment Navigation***

This security role allows you to navigate to the Tooling and Equipment module.

### ***Equipment Type Maintenance***

Allows users to maintain equipment types and equipment sub-types.

### ***Gauge Add/Edit***

This security role allows you to add new and edit gauges.

### ***Gauge Administrator***

This security role allows you to add new, edit, and remove gauges, gauge calibrations, and gauge R&R studies.

### ***Gauge Calibration Add/Edit***

This security role allows you to add new and edit gauge calibrations.

### ***Gauge Champion***

This security role allows you to add records in any process in the Gauge module.

### ***Gauge Maintenance***

This security role allows you to add, edit, and remove gauge types, gauge sub-types, gauge sub-type calibration standards, and gauge statuses. Typically this maintenance account is only given to one or two individuals responsible for setting up this data for others to use.

### ***Maintenance Champion***

This security role allows you to add, edit, and remove maintenance work orders preventive, maintenance work orders reactive, maintenance work order types, maintenance fault codes, maintenance teams, and maintenance procedures.

### ***System Administrator***

This maintenance security role allows you to add and remove security roles, domains, entities, sites, locations, generalized code types and codes, product lines, item groups, item types, review frequencies, company types, cost accounts, and units of measure. Besides being able to add and remove items, you can also view and edit all of the fields for the processes noted. Typically, this maintenance security role is only given to one or two individuals who are responsible for setting up the data for others to use.

### ***System View***

System view is a generic role that most users and modules use. This role allows you to view (but in most cases not edit) much of the non-sensitive data in the system. Being able to view the data is still subject to you having the ability to navigate to, and open, a process.

Every user should have this security role because it allows users to view non-secure data for most processes. For users who typically only have to approve data, but do not have to add or edit data, this System View role is what they need.

### ***Tooling and Equipment Administrator***

This security role allows you to add, edit, and remove records in any process in the Tooling and Equipment module.

### ***Tooling and Equipment Champion***

This security role allows you to add records in any process in the Tooling and Equipment module.

## **Process Security Roles**

Each list below displays the security roles that provide you with permissions to add items for the indicated individual process.

### **Tooling and Equipment Types**

- Equipment Maintenance
- Equipment Type Maintenance
- RFQ Administrator
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

### **Tooling and Equipment Status**

- Equipment Maintenance
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Maintenance Fault Codes**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Maintenance Teams**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Maintenance Work Order Types**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Maintenance Work Order Types Responsibilities**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Production Order Subsystems**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Production Order On Hold Reasons**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Cost Accounts**

- Cost Log Administrator
- Gauge Administrator
- Gauge Maintenance
- System Administrator
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Asset Meters**

- Equipment Maintenance
- Tooling & Equipment Administrator

- Tooling & Equipment Champion

## **Tooling and Equipment**

- Equipment Add
- Equipment Add/Edit
- Gauge Administrator
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Maintenance Procedures**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Maintenance Work Orders Preventive**

- Maintenance Champion
- Tooling & Equipment Administrator

## **Maintenance Work Order Reactive**

- Maintenance Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Tooling and Equipment Downtime Logs**

- Equipment Maintenance
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## **Cost Logs**

- APQP Administrator
- APQP Champion
- Cost Log Add/Edit
- Cost Log Administrator
- Gauge Administrator
- Maintenance Champion
- Projects Add/Edit
- Projects Maintenance
- Tooling & Equipment Administrator
- Tooling & Equipment Champion
- Worksheet Administrator

## Asset Usage Log

- Asset Usage Log Add/Edit
- Gauge Add/Edit
- Gauge Administrator
- Gauge Calibration Add/Edit
- Gauge Champion
- Tooling & Equipment Administrator
- Tooling & Equipment Champion

## State Change Security

As you complete tasks in the system, changes occur based on your activities (such as changing a record's state) and when other events occur (such as a specific amount of time passing). The changes based on your activities are called **actions**, while the event-based changes are called **triggers**. The main difference between the two is the initiator: actions are performed by users, and triggers are managed by the system.

Each system change may depend on a number of factors, including where you are in the system, who is involved, which fields are populated, and more. It is important to know the actions and triggers for each process because these affect your ability to complete a task.

The state change security for each process is separated into two sections:

1. **Security.** Which users (by security role or field role) can change the state of a record. Field roles are indicated with an asterisk\*.
2. **Transactions.** The conditions that must be met to initiate a trigger.

## Security

### Tooling and Equipment Types

| Transitions        | Tooling & Equipment Administrator | Tooling & Equipment Champion | Equipment Maintenance | Equipment Type Maintenance |
|--------------------|-----------------------------------|------------------------------|-----------------------|----------------------------|
| Active >> Inactive | ✓                                 | ✓                            | ✓                     | ✓                          |
| Inactive >> Active | ✓                                 | X                            | ✓                     | ✓                          |

### Maintenance Fault Codes

| Transitions        | Tooling & Equipment Administrator |
|--------------------|-----------------------------------|
| Active >> Inactive | ✓                                 |
| Inactive >> Active | ✓                                 |

## Maintenance Teams

| Transitions        | Tooling & Equipment Administrator |
|--------------------|-----------------------------------|
| Active >> Inactive | ✓                                 |
| Inactive >> Active | ✓                                 |

## Maintenance Work Order Types

| Transitions        | Tooling & Equipment Administrator |
|--------------------|-----------------------------------|
| Active >> Inactive | ✓                                 |
| Inactive >> Active | ✓                                 |

## Cost Accounts

| Transitions        | Cost Log Administrator | System Administrator |
|--------------------|------------------------|----------------------|
| Active >> Inactive | ✓                      | ✓                    |
| Inactive >> Active | ✓                      | ✓                    |

## Asset Meters

| Transitions        | Tooling & Equipment Administrator |
|--------------------|-----------------------------------|
| Active >> Inactive | ✓                                 |
| Inactive >> Active | ✓                                 |

## Production Order Subsystems

| Transitions        | Maintenance Champion | Tooling & Equipment Administrator | Tooling & Equipment Champion |
|--------------------|----------------------|-----------------------------------|------------------------------|
| Active >> Inactive | ✓                    | ✓                                 | ✓                            |
| Inactive >> Active | ✓                    | ✓                                 | X                            |

## Production Order On Hold Reasons

| Transitions        | Maintenance Champion | Tooling & Equipment Administrator | Tooling & Equipment Champion |
|--------------------|----------------------|-----------------------------------|------------------------------|
| Active >> Inactive | ✓                    | ✓                                 | ✓                            |
| Inactive >> Active | ✓                    | ✓                                 | X                            |

## Tooling and Equipment

| Transitions         | Equipment Add | Tooling & Equipment Administrator |
|---------------------|---------------|-----------------------------------|
| Active >> Inactive  | ✓             | ✓                                 |
| Active >> Retired   | ✓             | ✓                                 |
| Inactive >> Active  | ✓             | ✓                                 |
| Inactive >> Retired | ✓             | ✓                                 |

## Maintenance Procedures

| Transitions          | Maintenance Champion | Tooling & Equipment Administrator | Tooling & Equipment Champion |
|----------------------|----------------------|-----------------------------------|------------------------------|
| Draft >> Official    | ✓                    | ✓                                 | ✓                            |
| Official >> Obsolete | X                    | ✓                                 | X                            |

## Maintenance Work Orders Preventive

| Transitions                      | Maintenance Champion | Maintenance Team | Responsibility* | Tooling & Equipment Administrator |
|----------------------------------|----------------------|------------------|-----------------|-----------------------------------|
| Approval Rejected >> In Progress | ✓                    | ✓                | ✓               | ✓                                 |
| Assigned >> Complete             | ✓                    | ✓                | ✓               | ✓                                 |
| Assigned >> In Progress          | ✓                    | ✓                | ✓               | ✓                                 |
| In Progress >> Complete          | ✓                    | ✓                | ✓               | ✓                                 |
| In Progress >> On Hold           | ✓                    | ✓                | ✓               | ✓                                 |
| New >> Assigned                  | ✓                    | X                | X               | ✓                                 |
| On Hold >> Complete              | ✓                    | ✓                | ✓               | ✓                                 |
| On Hold >> In Progress           | ✓                    | ✓                | ✓               | ✓                                 |

## Maintenance Work Orders Reactive

| Transitions                     | Maintenance Champion | Maintenance Team | Responsibility* | Tooling & Equipment Administrator |
|---------------------------------|----------------------|------------------|-----------------|-----------------------------------|
| Approval Rejected >> In Process | ✓                    | ✓                | ✓               | ✓                                 |
| Assigned >> In                  | ✓                    | ✓                | ✓               | ✓                                 |

| Transitions            | Maintenance Champion | Maintenance Team | Responsibility* | Tooling & Equipment Administrator |
|------------------------|----------------------|------------------|-----------------|-----------------------------------|
| Process                |                      |                  |                 |                                   |
| Assigned >> On Hold    | ✓                    | ✓                | ✓               | ✓                                 |
| In Process >> Complete | ✓                    | ✓                | ✓               | ✓                                 |
| In Process >> On Hold  | ✓                    | ✓                | ✓               | ✓                                 |
| New >> Submit          | ✓                    | X                | X               | ✓                                 |
| On Hold >> In Process  | ✓                    | ✓                | ✓               | ✓                                 |
| Submit >> Assigned     | ✓                    | X                | X               | ✓                                 |

### Asset Usage Log

| Transitions         | Asset Usage Log Add/Edit | Gauge Add/Edit | Gauge Administrator | Gauge Calibration Add/Edit | Gauge Champion | Tooling & Equipment Administrator | Tooling & Equipment Champion |
|---------------------|--------------------------|----------------|---------------------|----------------------------|----------------|-----------------------------------|------------------------------|
| New >> Update Asset | ✓                        | ✓              | ✓                   | ✓                          | ✓              | ✓                                 | ✓                            |

## Transactions

### Maintenance Work Order Types

#### *Maintenance Type is Not RM*

When the Maintenance Type field is not set to "RM", the Responsibility Setup field is hidden.

### Cost Accounts

#### *Hide Quantity Unit of Measure if Allow Quantities is Not True*

When the "Allow Quantities" field is not selected, the following fields are hidden:

- Default Unit Cost
- Quantity Unit of Measure

## **Tooling and Equipment**

### ***Cavities Added***

When the cavity count control is incremented, the corresponding number of cavities is inserted in the record.

### ***Category is Empty***

The Category field is hidden when empty.

### ***Check Usage for Maintenance***

When the configured amount of hours in the Usage Frequency Hours field is reached, a preventive maintenance work order is created for the tool or equipment.

### ***Hide Location Field if it is Empty***

The Location field is hidden when empty.

### ***On Save***

When a process is saved, the downtime status is updated

### ***Status Changed***

When the status is changed, the status date and time are set.

### ***Status Changed to Inactive***

When the status is changed to Inactive, the hours at last inactive are calculated.

## **Maintenance Work Orders Preventive**

### ***Approval Rejected***

When the current state is changed to Rejected, a notification is sent to the Maintenance Champion to inform them that the work order has been rejected.

### ***Closed***

When the current state is changed to Closed, the current usage value of the equipment maintenance procedure is set back to the meter starting value.

### ***Equipment is Empty***

When the Tooling and Equipment field is blank, it is updated by the system based on the Equipment Maintenance Procedure field.

### ***Hide the Status Field if it is Empty***

The Status field is hidden when empty.

***In Process***

When a state is in process but was not in process prior, the Completed Date field is cleared.

***Responsibility Assigned and State is Assigned***

When the current state is Assigned and all responsibilities have been assigned, a notification is sent to the responsible employees to inform them that a work order has been assigned.

***State is Complete and No Approval***

When the current state is Complete and the work order type does not require approval, the state of the work order transitions to Closed.

***State is Complete and Requires Approval***

When the current state is Complete and the work order type requires approval, the state of the work order transitions to Ready for Approval.

***When Complete***

When the current state transitions to Complete, the Hours at Last Inactive field on the linked Tooling and Equipment record is reset to 0. Additionally, the system updates the Equipment Maintenance Procedure field if there are other work orders open for this tooling and equipment type.

***When Usage Type PM***

When the Equipment Maintenance Procedure's PM type is 'Usage', the record is updated to have a scheduling frequency of 'None'.

**Maintenance Work Orders Reactive*****Approval Rejected***

When the current state is moved to Rejected, a notification is sent to the Maintenance Champion to inform them that the work order has been rejected.

***Hide the Status Field if it is Empty***

The Status field is hidden when empty.

***Responsibility Assigned and State is Assigned***

When the current state is Assigned and all responsibilities have been assigned, a notification is sent to the responsible employees to inform them that the work order is assigned to them.

***Responsibility Assigned and State is Submitted***

When the current state is Submitted and all responsibilities have been submitted, a notification is sent to the responsible employees to inform them that the work order has been submitted.

### ***State is Complete and No Approval***

When the current state is Complete and the work order type does not require approval, the state of the work order transitions to Closed.

### ***State is Complete and Requires Approval***

When the current state is Complete and the work order type requires approval, the state of the work order transitions to Ready for Approval.

### ***When Complete***

When the current state transitions to Complete, the Hours at Last Inactive field is reset to 0.

## **Cost Logs**

### ***Containment Action Field is Null***

The Containment Action field is hidden when empty.

### ***Cost Account Allow Quantity is False***

If the selected cost account's "Allow Quantity" field is not selected, then the following fields are hidden:

- Quantity
- Unit of Measure

### ***Gauge Field is Null***

The Gauge field is hidden when empty.

### ***Hide CPR Task if it is Empty***

The CPR Task field is hidden when empty.

### ***Issue is Null***

The Issue field is hidden when empty.

### ***Nonconformance Field is Null***

The Nonconformance field is hidden when empty.

### ***Preventive Work Order Field is Null***

The Preventive Work Order field is hidden when empty.

### ***Project Field is Null***

The Project field is hidden when empty.

***Project Task Field is Null***

The Project Task field is hidden when empty.

***Reactive Work Order Field is Null***

The Reactive Work Order field is hidden when empty.

***Training Event Field is Null***

The Training Event field is hidden when empty.

**Asset Usage Log*****Gauge Field is Null***

The Gauge field is hidden when empty.

***Tooling and Equipment is Null***

The Tooling and Equipment field is hidden when empty.

***Update Asset***

When the current state transitions to Update Asset, the current usage value for the selected Tooling and Equipment or Gauge record is updated to the current value plus the value entered in the Usage Value field. For example, if the current usage value is 5 and 10 was entered into the Usage Value field, then the new current usage value would be 15.

Once this update occurs, the current state transitions to Complete.

**Commands**

Some processes utilize command buttons to perform pre-defined actions. Commands can be found under the Actions icon in the top toolbar of the appropriate process.

Below is a table that describes each command available in the Equipment Maintenance module. In addition to title and description, the table indicates which process each command comes from, the roles that can execute the command, and the states when the command can be executed.

| <b>Process</b>                    | <b>Title</b>          | <b>Description</b>                                                                                          | <b>Used By</b>                                                  | <b>State When Used</b> |
|-----------------------------------|-----------------------|-------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|------------------------|
| Maintenance Procedures            | Start New Version     | Initiates a new draft version of the record. The state of the previous version moves to Obsolete.           | Tooling & Equipment Administrator; Tooling & Equipment Champion | Official               |
| Maintenance Work Order Preventive | Adjust Schedule Dates | Opens the Scheduling Options dialog window, allowing you to modify the scheduling frequency for the current | Maintenance Champion; Tooling & Equipment Admin-                | New                    |

| <b>Process</b>                    | <b>Title</b>                         | <b>Description</b>                                                                                            | <b>Used By</b>                                          | <b>State When Used</b> |
|-----------------------------------|--------------------------------------|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------|------------------------|
|                                   |                                      | and future audits.                                                                                            | istrator                                                |                        |
| Maintenance Work Order Preventive | Change Frequency                     | Opens the Change Frequency Options dialog, allowing you to change the frequency of the audit.                 | Maintenance Champion; Tooling & Equipment Administrator | New                    |
| Maintenance Work Order Preventive | Delete Current Work Order Preventive | Removes the current work order from the system and, if required, updates the equipment maintenance procedure. | Maintenance Champion; Tooling & Equipment Administrator | All States             |

Chapter 7

# Module Frequently Asked Questions

*Frequently Asked Questions (FAQ)...77*

## Frequently Asked Questions

### *Why shouldn't I delete items?*

Records should only be deleted when you are sure that they are no longer needed. Even though records use a soft delete mechanism, there is still work that must be done to restore an item once it has been deleted.

The best thing to do with an item that is no longer needed is to set it to Inactive, Retired, or Obsolete, whichever state is applicable. This way, the item historically remains in the system but cannot be used.

If you do need to delete an item for good, then use the Trash button in the toolbar. Typically, only the system administrator can delete items.

### *I just changed the state of a process. What happens now?*

When a process' state makes a transition, the system typically takes some automated steps. Details about these steps are listed in the State Transitions section of each process in this user guide.

Typically, state transition steps perform one of three functions:

1. **Notifications.** Notifications are sent to the users that are responsible for the next state of a process.
2. **Field Update.** Fields that depend on a state, date, or action are updated.
3. **Another State Transition.** A process' state may be transitioned automatically by the system, depending on a state, date, or action update.

Some processes may not have any automatic state transitions. In that case, it is useful to check the States section to view the process' state map and read the definitions of each state.

You can also review the Task list for that process. Each list typically describes which state to select when saving a process record.